



FITTING AND CONNECTION INSTRUCTIONS

The **Compact 400/800** consists of a hydraulic pump and a hydraulic jack, both of which coupled in a **supporting box treated with cataphoresis**.

The pump unit casing, which is used as an oil tank, contains the electric motor, fluid pump, distributor and hydraulic oil.

It is also provided with an **adjustable slowing-down device** in the two stop phases of the leaf (versions with slow-down only).

The wheeling unit is composed by a double piston connected to a rack which engages with the pinion of the leaf dragging shaft.

Gates up to 2 meters long can be securely locked using the operators internal hydraulic locking system, thus ensuring perfect keeping in closing and in opening.

For gate in excess of stated value: A hydraulic non locking operator should be used in conjunction with a separate electrical locking device to ensure keeping in closing.

On the operators with hydraulic slow down it is present only during the last 15° of rotation.

The system comes with a release which allows the manual opening of the leaves in case of power failure.

MAIN PARTS NOMENCLATURE

- | | |
|---|-----------------------|
| 1 Braking regulation screw (where provided) | 5 Filling oil Cap |
| 2 Emergency release (authorized staff only) | 6 Water draining hole |
| 3 By-pass regulation | 7 Oil level indicator |
| 4 Exit hole for electric cables | 8 Draining screw |
| | 9 Greaser |
| | 10 Crank |




Fig. 1

TECHNICAL DATA	Compact 400	Compact 800
Power supply	230 V~ (±5%) 50/60 Hz	
Motor Power	220 W	
Absorbed current	1,1 A	
Motor rotation speed	1400 rpm	
Cycles hour (with a 20°C temp.)	45	
Max. Working pressure	50 bar	
Operating temperature	-20°C / +55°C	
Thermal protection intervention	130°C	
Max torque	56 da N	
Starting capacitor	12,5uF	
Weight	13 kg	13,8 kg
Protection class	IP 67	
Maximum weight of the gate	400 kg	800 kg
Braking regulation	On control unit or on operator*	

* In case of operator with hydraulic slow down

Note: The frequency of use is valid only for the first hour at 20°C room Temperature.

GRAPHIC FOR THE USE OF COMPACT 400 - 800 OPERATORS






Fig. 2



SEA®

Sistemi Elettronici
di Apertura Porte e Cancelli
International registered trademark n. 804888


CE

ENGLISH

1. GATE ARRANGEMENT

You must do some checks on the gate to see if fitting a COMPACT system is possible:


- A.** (Make sure that) the fixed and moving parts of the gate are strong and non-deformable;
- B.** the weight of each gate leaf must not exceed 400 kg (Compact 400), 800 kg (Compact 800), see the graphic (A);
- C.** the hinges and general structure must be in good condition and the gate must move smoothly throughout its travel;
- D.** the upper hinge alone is sufficient to install the unit; those which are unnecessary can be eliminated (the lower and that in the middle if exists);
- E.** as the limit switches are not provided within the actuator, it is necessary to install mechanical limit switches stops to be fixed to the ground in closing and in opening (Fig. 3).



2. CARRYING BOX INSTALLATION


2.1. The hole which contains the carrying box must have the approximate dimensions mentioned in Fig. 4.

For a correct placing, it is obligatory to follow closely the quote of 55 mm which corresponds to the minimum distance of the rotation axis from the pillar





2.2. Inside the excavated pit you have to plan:

- **rain water drainage;**
- a water waste pipe in flexible plastic of about 40 mm of diameter to put inside the provided hole of the box before it is concreted (Fig. 5). **It must be brought until the drain of the sewer line;**
- a sheath for the passage of electrical cables of about 20 mm of diameter which must be brought to the proximity of the electric connection box (Fig. 5).



2.3. Before concreting the carrying box, use a level to make it perfectly horizontal to the ground (Fig. 6) and perpendicular to the axis of the gate (Fig. 7).

The axis of the upper hinge of the gate must correspond exactly to the axis of the carrying box shaft.



2.4. introduce the buckle of creeping in the box and fix it with the special screws (Fig. 8).

2.5. Insert the units as in Fig. 8.

N.B.: During the insertion of the units lubricate them with the supplied grease.



SEA®

Sistemi Elettronici
di Apertura Porte e Cancelli
International registered trademark n. 904888

CE

ENGLISH




Fig. 8

3. LEAF ASSEMBLING

Before installing the gate make sure that the concrete has hardened into the foundation hole.

3.1. Position the leaf of the gate on the leaf device making reference to the rotation axe of the leaf hinge (Fig. 9);




Fig. 9

3.2. Weld with care the leaf device to the leaf of the gate realizing a tract fixation of ca. 3-4 cm along the surface of the contact, avoiding the welding next to the threaded holes, furthermore it is necessary to respect the perpendicularity to the axe of rotation (Fig. 10)




Fig. 10

3.3. Be careful not to place the leaf outside the axis (Fig. 12 and 13), but make sure the shaft corresponds to the hinge rotation axis remembering that the minimum distance from the pillar is 55 mm (Fig. 14).




Fig. 11




Fig. 12




Fig. 13




Fig. 14



SEA®

Sistemi Elettronici
di Apertura Porte e Cancelli
International registered trademark n. 804888



ENGLISH

4. INSTALLATION OF THE OPERATOR

4.1. Insert manually the operator into the carrying box (Fig. 15) also insert the splined shaft of the operator into the splined bush of the box and fix the operator with the special screws as in Fig. 17.




Fig. 15




Fig. 16

N.B.: It is advisable to weld the crank with the crank shaft after having also installed the Compact, to use the whole available run and the point of beginning of the desired slowdown (version with hydraulic slowdown).

Before welding, make sure that one of the level of the crank shaft corresponds with a side of the crank (see fig.16 and 17) to guarantee the maximum angle with the mechanical stops Kit.




Fig. 17

N.B.: If the Compact is not installed immediately but in a second time, it is recommended to weld the crank shaft and the crank during the installation of the Compact.

4.2. Carry out the electrical connections to the control unit as described in the instructions supplied with SEA control unit.

After ending all the operations in the installation of the above mentioned carrying box, of the gate and the operator, try to do some moves slowly by hand verifying that there are not irregular frictions and that the movement is uniform for the whole range.

Notice: To do this last operation, release the operator as described in the next paragraph.

5. MOTOR RELEASE SYSTEM

5.1. To release act as follows:

-Turn the release screw with the screwdriver about 180° ca. in anti-clockwise direction (Fig. 18).

5.2. To stop again act as follows:

-Turn the release screw with the screwdriver into clockwise direction until it stops.




Fig. 18

6. MOUNTING OF THE RELEASE

For the Compact there are foreseen two types of release: **RELEASE** (with personalised key) and **RELEASE PLUS** (with DIN key).

RELEASE

6.1. Grease the hinge (A) and mount the release system under the leaf device using the 4 furnished screws (Fig. 19)




Fig. 19

RELEASE PLUS

6.2. Grease the hinge (A) and mount the release system under the leaf device using the 5 furnished screws (Fig. 20).




SEA[®]

Sistemi Elettronici
di Apertura Porte e Cancelli
International registered trademark n. 804888

CE

ENGLISH

Fig. 20



Carry out the electrical connections to the control unit as described in the instructions supplied with SEA control unit.

7. ADJUSTABLE MECHANICAL STOPS




Fig. 21




Fig. 22




Fig. 23




Fig. 24




Fig. 25




Fig. 26

LEFT




Fig. 27

RIGHT




Fig. 28

When putting in function the installation it is peremptory to lubricate the box as in Fig. 31 until the grease comes out. (Use grease type DIN 51502 KP 2 N-20 - K2 K-20).



SEA®

Sistemi Elettronici
di Apertura Porte e Cancelli
International registered trademark n. 804888

CE

ENGLISH

8. REGULATION OF THE PUSHING FORCE

The pushing force or anti-crushing force must be valued by hand or better with a dynamometer and in both the ways of rotation.

To regulate such force act as follow:

act on the by-pass valves with the provided key, given to the authorised installers, clockwise to increase the force, anti-clockwise to decrease it (Fig. 29).




Fig. 29

The adjustment is carried out with the gate moving and will not change the speed of the leaf.

Notice: The maximum regulation is of 15Kgf following the UNI EN 12453 law.

The motor run time is the last adjustment to make. It should be set 2 to 4 seconds higher than it takes to the gate to reach its stop. (this last regulation must be done on the electronic control unit).

9. BRAKING REGULATION (where present)

9.1. It is possible to regulate the leaf slowdown in opening and in closing, through the braking adjusting screw (Fig. 30).

9.2. To regulate slowdown operate as follow:

- Loosen the blocking screw of braking regulation
- Act on the adjusting screw clockwise to have a higher braking and a speed decrease;
- Act on the adjusting screw anti-clockwise to have a lower braking and a speed increase;
- After the regulation fix the blocking screw of braking regulation.

On the operators with hydraulic slow down it is present only during the last 15° of rotation.




Fig. 30

To the attention of users and technicians

10. RELEASE SYSTEM OF THE LEAVES

RELEASE

10.1. To release act as follows:

-Insert the enclosed key into the keyhole (S) and turn the handle about 180° against the centre of the gate (Fig. 31).

-Keep the key locked and move the leaf, now turn back the key to the normal position and extract it.

10.2. To stop again act as follows:

-Move the leaf until the lock has coupled again.




Fig. 31

RELEASE PLUS

10.3. To release act as follows:

-Insert the enclosed key into the keyhole and turn it about 90° in clockwise direction (Fig. 32).

- Pull the key against the external of the release making come out the handle of the lock until it reaches the stop (Fig.33).

- Move the leaf and make return the handle of the release in its original position and extract the key.

10.4. To stop again act as follows:

-Move the leaf until the lock has coupled again.




Fig. 32




Fig. 33



SEA®


Sistemi Elettronici
di Apertura Porte e Cancelli
International registered trademark n. 804888



ENGLISH


To the attention of users and technicians

11. CABLE LAYOUT (Fig. 34)



12. RISK EXAMINATION


The points pointed by arrows in Fig. 35 are potentially dangerous. The installer must take a thorough risk examination to prevent crushing, conveying, cutting, grappling, trapping so as to guarantee a safe installation for people, things and animals (Re. Laws in force in the country where installation has been made.).



SEA can not be deemed responsible for any damage or accident caused by product breaking, being damages or accidents due to a failure to comply with the instructions herein. Read the general instructions attentively.

SAFETY GATE


For a correct and safe installation it is strongly recommended to install a Safety Gate, **which allows the fulfilment of the force diagram included in the norm EN 12453** and consequently the test and start of the whole installation.




PERIODICAL MAINTENANCE

Check the oil level (Trasparent cap n.7 in Fig. 1)	Annual
Change the oil	4 years
Verify the functionality of the by-pass valves (check the force in opening and closing)	Annual
Check the release function	Annual
Verify the slowdown regulation (where present)	Annual
Check the correct drain of the rainwater	Annual
Check the integrity of the connection cables	Annual
Grease all the moving parts	Annual
Grease the rotation axis of the box as in Fig.28	Annual


ACCESSORIES FOR COMPACT




CARRYING BOX INOX




RELEASE



RELEASE PLUS



SAFETY GATE



KIT MECHANICAL STOP

SAFETY PRECAUTIONS:

All electrical work should conform to current regulations. A 16 A 0,030 A differential switch must be incorporated into the source of the operators main electrical supply and the entire system properly earth bonded. Always run mains carrying cables in separate ducts to low voltage control cables to prevent mains interference.

SPARE PARTS:

To obtain spare parts contact:

SEA s.r.l. - Zona Ind.le, 64020 S. ATTO Teramo Italia

SEA reserves the right to do changes or variations that may be necessary to its products with no obligation to notice.