

UNIGATE 1I - 2I - 1I BIG - 2I BIG

UNIGATE 2PM

UNIGATE BR

SEA S.p.A.

Zona industriale 64020 S.ATTO Teramo - (ITALY)
Phone +39 0861 588341 r.a. Fax +39 0861 588344
www.seateam.com seacom@seateam.com

COMPONENTS

CONTROL UNIT PRIMARY POWER SUPPLY:

230 Vac 50/60 Hz - 115Vac 50/60 Hz

POWER CONSUMPTION IN STAND BY:

30 mA

ENVIRONMENT T° RANGE:


- (20)°C +50°C

DIMENSIONS OF EXTERNAL BOX:

325,7 X 246 X 140 mm

DO NOT CONNECT THE CAPACITORS

if the motor is combined with the **UNIGATE 1-I or 2-I** control unit



CONNECTIONS

CN1 = Input/output connectors

CN2 = Limit switch, 24V~, Electric lock connector

CN3 = Encoder terminal board/PositionGate/ gp1/gp2

Jolly/Cloud connector Jolly 3 or Sea Cloud

FIX = FIX receiver plug in connector

CR1 = Relay 1 dry contact terminal

CR2 = Relay 2 dry contact terminal

2PM = 2PM module power supply connector

CNB = Batteries charger connector

CNP = Programming connector

CLS = Limit switch quick connector

Power - + = Power supply switching connector

Module 1 = connector FV module for motor 1,

2PM module for motors 1 and 2 , BR module for motor 1

Module 2 = connector FV module for motor 2 , 2PM module for motors 3 and 4 , BR module for motor 2

Master/Slave = Master/Slave card connector

Progr = Programming connector through Open


Exp = external module connector SEM 2, RS485

CNR = UNI receiver connector

Battery = Back up battery for timer type CR 2032

MEM = Radio transmitters memory for FIX receivers

CONNECTIONS



Revision Firmware

V.03.00
and following (V.xx.xx)
for **module 2PM**

I.03.01
and following (I.xx.xx)
for **module INVERTER**

B. 00.21
and following (B.xx.xx)
for **module BR**

Warning: Automatic detection of not used N.C. inputs (Photocells, Stop, Limit switch and Edges)



To reactivate a NC contact, follow this procedure:

Go to **MENU 1 LANGUAGE** and press **OK** for 5 seconds, then enter the **INPUT CHECK MENU** and

check the operating status of all inputs


No need to repeat self programming after reactivation of N.C. contacts.

The herein reported functions are available starting from revision


I 03.11 for Inverter, B 00.27 for BR , V 03.02 for 2PM

CONNECTIONS



CN1




CN2




CN3




CR1 - Relay 1




CR2 - Relay 2



Power 24V




UNIGATE 1I - 2PM CONNECTION WITH AN INVERTER MODULE






It is mandatory to connect the ground cable to the PE input

UNIGATE 2I CONNECTION WITH TWO INVERTER MODULES



It is mandatory to connect the ground cable to the PE input


UNIGATE 11 - 2PM CONNECTION TO EXTERNAL UPS AND
CHECK EMERGENCY OPERATING (MENU 113)



INPUTS - OUTPUT CONNECTIONS


- N.C. normally closed - N.O. normally opened

A) COMIS Function (for load control) - 350 mA




The COMIS input can be used as common for accessories up to a maximum load of 350 mA, the exceeding of the maximum load will appear on the display.

To check the consumption of the accessories, connect the negative of the accessories to input (20) CN2 and the positive to the input (19).



B) CONFIGURATION 24V DC AUX CN1




On the 24V AUX you can select when and how to operate the connected auxiliary accessory. See special menu

MENU 94
24V AUX

For photocells it is recommended to set the 24V aux as in *cycle and phototest*, in order to have the security of operation and energy saving.

The maximum load for this output is 1A, and refers to the sum of the loads on the single outputs 24 VDC AUX and 24 VDC.



On 24V DC must be connected all accessories that shall always be active. Example: external receivers.

The maximum load for this output is 1A, and refers to the sum of the loads on the single outputs 24 VDC AUX and 24 VDC.

D) SAFETY

D.1) PHOTOCELLS - LOOP







photo 1 photo 2

Photocell 1 and Photocell 2 (Loop1 - Loop2)
11 and 12 aux ~ (Accessories) 1A max
COM = 0V

7 PH1 = Photocell contact 1


8 PH2 = Photocell contact 2



Default settings:

PHOTO 1 = “Close” - PHOTO 2 = “Open”
Photocell 2 can also be set as TIMER (see MENU 92 TIMER).

For photocell options, see menu 97 and 98:





TIMER:

keep (8) PH2 pressed, the gate opens and remains open, while, when released, the gate repeats the selected pause time and starts closing. If a safety device is activated, the Timer resets automatically after 6 sec.

AUTOTEST function: make sure that the photocells work properly before any movement. If the test fails, it will be indicated on the display.


To activate the AUTOTEST:

1) Connect the positive of the photocell TX to be tested on the input as in *cycle and phototest*



2) Go to the menu and select on which accessory (Photocell 1 or Photocell 2 or both) to activate this mode.

D.2) 10K PHOTOCELL SIMPLE OR DOUBLE



is also possible to connect a 10K Photocell.




it is necessary to set the relative photocell as a 10 K PHOTO and at this point it will work according to the settings given by the menus:




Note1: Using the 10K Photocell, further protection will be provided also in the event of a short-circuit on the cables.

Setting 10 K Photocell



D.3) SAFETY EDGE



It is possible to connect a safety edge between the contacts

(or two edges, with the second one connected between the contacts 10 and 11).

When pressed, the Safety Edge opens the contact causing a reverse of the movement both in opening and in closing. The Safety Edge input can be set «only in closing», «only in opening» or both. See menu 102 and 103.

MENU 102
SECURITY EDGE
1 DIRECTION

MENU 103
SECURITY EDGE
1 DIRECTION

In closing it is possible to choose whether to have the partial or total reverse. See

MENU 46
CLOSING INVER-
SION


Note1: Through the display or the JOLLY 3 programmer it is possible to activate the balanced edge 8K2, in this case the edge contact is controlled by a special resistance value revealing the eventual involuntary short-circuit of the device. In case of malfunctioning of the device a special alarm will be shown on the display or on the JOLLY 3 programmer.

It is also possible to set two 8K2 Safety Edges on each single input Safety Edge.

See menu100 and 101

MENU 100
Safety Edge 1


MENU 101
Safety Edge 2



Note2: Self-test can be made also on a powered radio Edge

See


MENU 96
AUTOTEST




D.4) POSITION GATE (LINEAR ABSOLUTE ENCODER)

The POSITION GATE allows to know the exact position of the gate and to have the reverse on the obstacle.

The POSITION GATE is applicable on the hydraulic motors HALF TANK and MINI TANK new series, in combination with the LE card.




To use the POSITION GATE, activate it in the menu:



! If the reading of the potentiometer is reversed compared to the movement of the motor, on the display will appear the alarm “Potentiometer direction” and you will have to reverse the brown wire with the green one and repeat programming.

! Note: for distances of more than 2 meters, it is recommended to connect a shielded cable with a sheath connected to COM 25





Adjustable sensitivity intervention threshold. See menus 33 to 45.
The sensitivity on the obstacle is adjustable from 0 - 99%. Higher is the percentage, more difficult it will be to detect the obstacle. 10% fast reverse - 99% slow reverse
To check the correct operation of the POSITION GATE, go to the menus




through which it is possible to check that by manually moving the leaf the pulses will vary from a value of about 100 in closing to about 6000 in opening.





D.5) ENCODER CONNECTIONS MAGNETIC



The encoder allows to know the position of the gate and to have the reverse on the obstacle.
To use the encoder it's necessary to activate it in the appropriate




CN3



The sensitivity on the obstacle is adjustable from 0 - 99%.
Higher is the percentage, more difficult it will be to detect the obstacle

To check the correct operation of the Encoders, go to the menu

through which it is possible to check if during operation of the leaf the pulses vary from the value of 0 in closing to the value memorized in learning, visible in the menu



**D.6) AMPEROMETRIC DEVICE FOR
ELECTROMECHANICAL OPERATORS**

This control unit comes with an obstacle detection system working only on electromechanical operators allowing to have the reverse on obstacles and the automatic detection of the stops. Sensitivity adjustable from Menu 33 to 37, from OFF to 99% in the special menu.

MENU 33 OPENING SENSITI- VITY MOTOR 1	MENU 34 CLOSING SENSITI- VITY MOTOR 1	MENU 35 OPENING SENSITI- VITY MOTOR 2	MENU 36 CLOSING SENSITI- VITY MOTOR 1	MENU 37 SLOWDOWN SENSI- TIVITY MOTOR
---	---	---	---	--

Higher is the percentage, more difficult it will be to detect the obstacle detection.
On hydraulic unit this parameter will be always OFF.

10% fast reverse 99% slow reverse



To adjust current intervention threshold instead you have to act on menus from 140 to 147.



from 1 to 10A




MENU 140 THRESHOLD A OPENING 1	MENU 141 THRESHOLD A CLOSING 1	MENU 142 THRESHOLD A OPENING 2	MENU 143 THRESHOLD A CLOSING 2
MENU 144 THRESHOLD A OPE- NING SLOWDOWN 1	MENU 145 THRESHOLD A CLO- SING SLOWDOWN 1	MENU 146 THRESHOLD A OPE- NING SLOWDOWN 2	MENU 147 THRESHOLD A CLO- SING SLOWDOWN 2

E) COMMANDS

E.1) PEDESTRIAN START (N.O.)

the pedestrian opening allows the total or partial opening of one single leaf in percentage of the learned space.




- **Function 1 (STANDARD):** partial opening space adjustable from 5% to 100% MENU 90
PARTIAL
OPENING
- **Function 2 (TIMER)**  : by holding the pedestrian  the gate opens and remains open.
If released, the gate repeats the selected pause and starts closing. In case of a safety device activation the timer will automatically reset after 6 sec.
- **Function 3 (2 BUTTONS):** in 2 buttons logic press the pedestrian Start  to close the gate.
- **Function 4 (DEADMAN):** in deadman logic this button executes the re-closing if you keep it pressed.

E.2) STOP (N.C.)




When pressing this button the motor immediately stops in any condition/position.
To re-start the movement, give a start command. After a stop the motor always re-starts in closing.


E.3) START (N.O.)




- **Function 1 (STANDARD):** an impulse given to this contact opens and closes the automation depending on the selected logic. See menu MENU 6
LOGIC

- **Function 2 (TIMER)**  : by holding START the TIMER function is activated, releasing the Start, the operator repeats the Pause and then re-closes. To connect other devices (e.g. the loop) refer to the related instructions leaflets (ie. loop detectors and proximity Switches). In case of activation of a safety device the timer will automatically reset after 6 seconds.
- **Function 3 (2 BUTTONS):** in 2 buttons logic this button performs the opening.
- **Function 4 (DEADMAN):** in deadman logic keep pressed the Start for the opening of the automation.

CN1



E.4) LIMIT SWITCH CONNECTIONS



No jumper needed when not connected.

For the limit switch function, limit switches must be installed, both in opening and closing. In the case of single-leaf connect motor 1 (it is not necessary to bridge the limit switches of motor 2).

ANTI-INTRUSION




Anti-intrusion function can be activated. This function needs at least one limit switch, which pushes the motor in closing direction once it's released.


For the correct functioning of the limit switches there must be a correspondence between the direction of movement of the motors and the respective engaged limit switches.

MENU 79
ANTI INTRUSION

CN2



CLS




Quick connector sliding limit switch

UNIGATE 1I - 2I


Note 1: On the Big Fast slide motor, the opening and closing limit switches of motor 2 are used as slowdown limit switches. On the JOINT 4 LS, the slowdown limit switches must be connected to inputs 24 and 26 of CN3.

CN2




Example of connection with BIG Fast

CN2




CN3



Example of connection with JOINT 4 LS and bollards on Menu 12 - ON

Note 2: If 2 Big Fast or JOINT 4 LS motors are connected, the opening and closing limit switches of motor 1 and motor 2 will be connected to the CN2, the slow down limit switches of motor 1 and motor 2 will be connected to the CN3, as following:



Note: in the case of two 2 PM modules (3 or 4 motors), the limit switches of motors 3 and 4 must be connected in parallel respectively to the opening and closing limit switches M1 and M2.

UNIGATE 2 PM

Note: in case of 2 modules 2 PM (3 or 4 motors), the limit switch (LS1 e LS2) of motors 3 and 4 must be connected in parallel respectively the limit switches in opening and closing M1 ed M2

LS= limit switch

O1 = opening motor 1

O2 = opening motor 2

O3 = opening motor 3


O4 = opening motor 4

C1 = closing motor 1

C2 = closing motor 2

C3 = closing motor 3


C4 = closing motor 4




ENCODER ON BIG 4000



- 1 = RED
- 2 = WHITE
- 3 = BLACK
- 4 = YELLOW




UNIGATE



EXP

board RS485

E.5) LATCH OPENING & LATCH CLOSING



MENU 118
LATCH


Latch open / Latch close function:

Inputs 9 and 10 can be set accordingly as latch open and latch close - see menu 118. In this case they will lose their function as safety edge.

*latch opening
(locked open)*



*latch closing
(locked closed)*



no
command
accepted




With 118 Menu you can set the following functions:

1. Latch Opening
2. Latch Closing
3. Opening & Closing
4. Off

1) Latch Opening:



2) Latch Closing:



3) Opening & Closing:

To set both functions.

4) Off:

To deactivate both functions.

With the TX remote control you can set the following functions:

1. Latch Opening
2. Latch Closing

1) Latch Opening:

Use the 2 Transmitters menu: program the TX as Latch Opening


2) Latch Closing:

Use the 2 Transmitters menu: program the TX as Latch Closing

With the Sea Cloud System you can set the following functions:


1. Latch Opening
2. Latch Closing

CN1




Latch Opening

Latch Closing



**If inputs 9 and 10 are used as latch opening and latch closing functions, they can no longer be used as edge security 1 and edge security 2.*

E.6) PROGRAMMABLE INPUTS GP1 AND GP2



These inputs can have different functions, depending on how they are set in menus 130 and 131

MENU 130
GP1

MENU 131
GP2

CONNECTION OF TEMPERATURE PROBE (PROBE)



1) Unscrew the cap



2) Screw in the PROBE




3) The two cables must be connected between 27 and 29 or 28 and 29



4) Enter the menu **MENU 130 GP1** or **MENU 131 GP2** depending on where the probe is connected and set them up for the "thermometer function"

5) **MENU 109 THERMOMETER**: if active the thermometer displays the temperature




7) Enter the menus **MENU 110 LOWER THRESHOLD TEMPERATURE** and **MENU 111 UPPER THRESHOLD TEMPERATURE** to change parameters

and set the minimum activation temperature threshold and the maximum activation temperature threshold. (T minimum threshold -5 ° C, T maximum threshold 0 ° C)

CONFIGURATION AS "EMERGENCY OPENING"

Go to the GP1 or GP2 menu and set the "Emergency opening".




F) ACCESSORIES OUTPUT

F.1) FLASHING LAMP- BUZZER

24V FLASHING LAMP 3W MAX


The 24V Flashing Lamp is connected between the connectors



The Flashing lamp advises that the automatic gate is moving with 1 flash/second in opening and 2 flashes/seconds in closing. During pause it remains switched on. Through the warning lamp it is also possible to identify alarms for the STOP, PHOTOCELL 1, PHOTOCELL 2 and EDGE 1 and EDGE 2 devices. Through the display or the JOLLY 3 programmer it is possible to activate the pre-flashing function and/or to modify the function of the flashing lamp choosing between fix flashing or control lamp. The preflashing can be timed from 0 to 5 seconds otherwise it is possible to set it before closing only.



1 Flash
2 Flashes
3 Flashes
... and more




BUZZER (24V) AUDIBLE ALARM

Important note: instead of the flashing lamp, you can also connect a buzzer in this case set the 86 *FlashInG lIght* menu on

MENU 86
BUZZER

Use an autoswinging buzzer 24V of 100 dB. The buzzer will be activated after two consecutive activations of the entrapment protection. To reset the alarm it is necessary to push the STOP button. In any case after 5 minutes the buzzer will stop to sound and the automation stops waiting for commands.

If Buzzer does not work, check if the 86 - *FlashInG lIght* menu is set on "Buzzer"




2 times




buzzer

STOP
5 minutes



F.2) ELECTRIC-VALVE

A 12V=15W max electric lock can be connected



The electric lock can be deactivated when not used for energy saving on the control unit. The electric lock release can be timed from 0 to 5 seconds.

See menu

MENU 77
LOCK TIME

The electric lock can be set: only "before opening", only "before closing" or in "both directions". See menu

MENU 78
LOCK

→ only in OPENING

→ only in CLOSING

→ OPENING and CLOSING

To facilitate the release of the electric LOCKIT it is possible to set PUSHING STROKE, see

MENU 76
PUSHING
STROKE

→ TIME OFF - 3 sec.

→ REPEAT OFF - ON



G) RELAY 1 and RELAY 2 management (CR1 e CR2)

The dry contact outputs CR1 and CR2 can be used for different functions, which can be set through the menus

MENU 132
RELAY 1


MENU 133
RELAY 2

G.1) BOLT LOCK




Note:

set on
the menu




G.2) ELECTRIC VALVE CONNECTION

230/115V electric valve connection




12/24V electric valve connection

note: the 24V ext must be supplied by an external power supply of suitable power.




Note:
set on the menu




G.3) TRAFFIC LIGHT

Menu 131 - 132


in entrance
connection 115/230V




in exit
connection 115/230V



in entrance
connection 24V



in exit
connection 24V



note: the 24V ext must be supplied by an external power supply of suitable power.

For Special Function see

MENU
89 TRAFFIC
LIGHT

TIME SLOT SETTINGS ON CLOCK MENU 1, 2, 3 AND 4 (MENU FROM 124 TO 127)

default 8:00 --> 12:00
active days in OFF


MENU 127
CLOCK 4

MENU 126
CLOCK 3

MENU 125
CLOCK 2


MENU 124
CLOCK 1

The settings for menu 124 are
also valid for menus 125, 126
and 127.



SETTING OF TIME BANDS

up to 4



MASTER/SLAVE CIRCUITS CONNECTION

It is possible to use the Master/Slave configuration on **OPPOSED SLIDING GATES, OPPOSITE BARRIERS or BOLLARDS** moved by two operators **EACH MANAGED BY A CONTROL BOARD**


To work in Master/Slave it is necessary to use the **MASTER/SLAVE KIT** (code SEA 23001220) consisting of two circuits to be connected to the control units through the CMS connector, then setting a control unit as **Master** and the other as **Slave**

⚠ ATTENTION: In the Master/Slave configuration it is necessary to connect all the accessory devices (photocells, key button, safety edge, etc.) on the control unit set as **MASTER** which will also control the operator movement linked to the control unit set as **SLAVE**. The latter will allow you to adjust only the functions of the following menus:


1-LANGUAGE	48-MOTOR 1 TOTAL ENCODER	88-COURTESY LIGHT
3-ENGINE	59-MOTOR 1 OPENING SLOW-DOWN	94-24V AUX (EXCEPT AUTOTEST FUNCTION)
5-REVERSE MOTOR	60-MOTOR 1 CLOSING SLOW-DOWN	104-SELECT LIMIT SWITCH
14-RESET	63-DECELERATION	105-DIAGNOSTICS
17-MOTOR 1 OPENING SPEED	64-ACCELERATION	112-PASSWORD
18-MOTOR 1 CLOSING SPEED	65-MOTOR 1 OPENING TIME	115-DECELERATION RAMP
21-MOTOR 1 SLOWDOWN SPEED IN OPENING	66-MOTOR 1 CLOSING TIME	123 - 127 DATE AND TIME MENUS
22-MOTOR 1 SLOWDOWN SPEED IN CLOSING	70-OPENING POSITION RECOVERY	130 - 135 RELAY MENUS
28-MOTOR 1 OPENING TORQUE	71-CLOSING POSITION RECOVERY	137-COMIS
29-MOTOR 1 CLOSING TORQUE	72-MOTOR 1 OPENING TOLERANCE	140-THRESHOLD A OPENING 1
32-ENCODER	73-MOTOR 1 CLOSING TOLERANCE	141-THRESHOLD A CLOSING 1
33-MOTOR 1 OPENING SENSITIVITY	76-PUSHING STROKE	144-THRESHOLD A OPENING SLOWDOWN 1
34-MOTOR 1 CLOSING SENSITIVITY	78-LOCK	145-THRESHOLD A CLOSING SLOWDOWN 1
37-SLOWDOWN SENSITIVITY	83-EXTRA TIME	
47-MOTOR 1 PARTIAL ENCODER	86-FLASHING LIGHT	

⚠ * INSTALL AND CONFIGURE THE TWO OPERATORS AS IF THEY WERE TWO INDEPENDENT INSTALLATIONS; THEN CHECK THEIR CORRECT OPERATION AND THE CORRECT READING OF THE LIMIT SWITCHES, IF PRESENT


MASTER / SLAVE SETTING




①





②



③



④



⑥ M1 CONTROL UNIT CONFIGURATION AS MASTER




⑦ M2 CONTROL UNIT CONFIGURATION AS SLAVE




⑧

ONCE SET EACH UNIT IN MASTER OR SLAVE, SEND A START COMMAND TO THE UNIT SET AS MASTER



SINGLE MOTOR AND DRY RELAY CONTACT CONNECTION



MOTOR 1

Motor connection 1

The motor must be connected to the terminal block CN2 of the Inverter module, in terminals U, V, W. - **DO NOT CONNECT THE CAPACITORS**

In case of two motors, connect the second motor to the second Inverter module, again in the CN2 terminal board.

U: black

V: blue

W: brown

Check if the gate starts in closing direction otherwise you need to invert the black with the brown cable of the motor connections

For special functions see



MENU 134
RELAY FV 1

MENU 135
RELAY FV 2


- Positive Brake
- Negative Brake
- Negative Brake photocells
- Cooling fan

Dry relay contact max 5A (BR BR)


Dry contact can be set on



OK to confirm





POWER INPUT



Note: Note: it is mandatory to connect the earth cable to the PE.
We recommend using a differential switch 16A at the beginning of the system

BRAKE CONNECTIONS




Note:

On the sliding motor BIG/Relay FV1 it is set by default as photocell negative brake management

- ① green
- ② yellow
- ③ blu
- ④⑧ red
- ⑤ white
- ⑥ brown
- ⑦ black

THREE-PHASE POWER SUPPLY 400 VAC

ALIMENTATION TRIPHASÉE 400 VAC



POWER SUPPLY 230 Vac

UNIGATE 2 PM

SINGLE MOTOR AND DRY RELE CONTACT CONNECTION

MOTOR 1

Motor connection 1

The motor must be connected to the terminal block CN3 of the 2 PM module, in terminals 36, 37, 38.



Motor to be connected in the case of a single leaf.
In the case of two motors, connect the second motor in the CN 2 terminal board (31, 32, 33).

CABLE COLOUR	230 V	115 V
Phase 1	black	black
Neutral	blue	white
Phase 2	brown	red

POWER INPUT


To connect the power supply, follow the regulations in force.

Check if the gate starts in closing direction otherwise you need to invert the black with the red cable of the motor connections.



UNIGATE BR

CONNECTIONS 1 OR 2 BRUSHLESS MOTORS



MOTOR 1



Motor connection 1

The motor must be connected to the terminal block CN1 of the Inverter module, in terminals U, V, W.

On PE it is recommended to connect the ground cable

In case of two motors, connect the second motor to the second Inverter module, again in the CN1 terminal board.

Check if the gate starts in closing direction otherwise you need to invert the black with the brown cable of the motor connections



OUTPUT 24V

To be connected to input POWER on the UNILOGIC module

POWER 20-48V
(Note: the 20-48vdc power supply can come from external switching power supply 300 Va or from rectifier bridge with transformer)



PARAMETER AND NO/NC CONTACTS CHECK STATUS

The input status check menu appears at the start of the control unit (for details see chapter 4). Each input corresponds to a fixed position on the display, according to the diagram below and can be Normally Open (N.O.) or Normally Closed (N.C.).

STEP 1)


- A. Turn on the control board
- B. The firmware version number appears
- C. After about 5 seconds, the status of the inputs indicated by 0 or 1 appears

Note: the control unit back light characters display, when not in programming, is always set as shown in the figure.

For more information on the previous lcd segments display: see the Unigate rev 01, rev 02 or rev 03 manuals


- 0 = open contact (N.O.)
- 1 = closed contact (N.C.)

- 1 Start
- 2 Start pedestrian
- 3 Stop
- 4 Photo 1
- 5 Photo 2
- 6 Security Edge 1
- 7 Security Edge 2
- 8 not used
- 9 Limit switch opening motor 1
- 10 Limit switch closing motor 1
- 11 Limit switch opening motor 2
- 12 Limit switch closing motor 2
- 13 not used (slowdown limit switch - Opening motor 1)
- 14 not used (slowdown limit switch - Closing motor 1)
- 15 not used (slowdown limit switch - Opening motor 2)
- 16 not used (slowdown limit switch - Closing motor 2)




The symbol «1» lit indicates that, during the self-learning phase, the input status is closed or disabled

- When N.C.
(Photo, Stop, Limit switch and Edge)




When not engaged or not wired



contacts n.c.

When the photocell is crossed or input is engaged



contacts n.o.

- When N.O.
(Start, pedestrian start)



When input is engaged




When input is not engaged

STEP 2)

Power OFF




STEP 3)




Keep pressed the two buttons **UP** and **DOWN** and, at the same time, switch the power supply in ON for initialization of the control unit, INIT appears on the display

or go to



All parameters return to default factory configuration, see column “Default” in the table of the menus and all the inputs will show their real status



= N.O. contacts



= N.C. contacts

To reactivate the NC contacts it is necessary to enter each menu which shows the NC contacts (e.g.: STOP, PHOTO, EDGE....) and with SET put them on ON.

INPUTS CONTROL MENU

MENU 1
LANGUAGE



Enter the menu **MENU 1 LANGUAGE** and press the button **OK** for 5 seconds, you can enter the *check MenU*, where it is possible to check the operating status of all inputs.

MENU FUNCTION TABLE

To access the Menu for input control press the button OK for 5 seconds

Menu			Description	Description
START ON/OFF	OK	<div><div>UP</div><div>DOWN</div></div> <div>Enabled</div> <div>Blocked</div>	Prova Start	Contact = N.O. Default = OFF If switching the command on the display from OFF to ON the input will work. If ON is always active, check the wirings.
STOP ON/OFF	OK	<div><div>UP</div><div>DOWN</div></div> <div>Enabled</div> <div>Blocked</div>	Prova Stop	Contact= N.C. Default = ON If switching the command on the display from OFF to ON the input will work. If ON is always active, check the N.C. contact.
START PARTIAL OPENING ON/OFF	OK	<div><div>UP</div><div>DOWN</div></div> <div>Enabled</div> <div>Blocked</div>	Partial Opening Test	Contact = N.O. Default = OFF If switching the command on the display from OFF to ON the input will work. If ON is always active, check the wirings.
EDGE 1 ON/OFF	OK	<div><div>UP</div><div>DOWN</div></div> <div>Enabled</div> <div>Blocked</div>	Safety edge 1 test	Contact = N.C. Default = ON If switching the command on the display from ON to OFF the input will work. If OFF is always active, verify that the contact is a N.C.
EDGE 2 ON/OFF	OK	<div><div>UP</div><div>DOWN</div></div> <div>Enabled</div> <div>Blocked</div>	Safety edge 2 test	Contact = N.C. Default = ON If switching the command on the display from ON to OFF the input will work. If OFF is always active, verify that the contact is a N.C.
PHOTO 1 ON/OFF	OK	<div><div>UP</div><div>DOWN</div></div> <div>Enabled</div> <div>Blocked</div>	Photocell test 1	Contact = N.C. Default = ON If switching the command on the display from ON to OFF the input will work. If OFF is always active, verify that the contact is a N.C.
PHOTO 2 ON/OFF	OK	<div><div>UP</div><div>DOWN</div></div> <div>Enabled</div> <div>Blocked</div>	Photocell test 2	Contact = N.C. Default = ON If switching the command on the display from ON to OFF the input will work. If OFF is always active, verify that the contact is a N.C. S
M1 Opening Limit Switch ON/OFF			M1 Opening Limit Switch Test	Contact = N.C. Default = ON If switching the command on the display from ON to OFF the input will work. If OFF is always active, verify that the contact is a N.C.
M1 Closing Limit Switch ON/OFF			M1 Closing Limit Switch Test	Contact = N.C. Default = ON If switching the command on the display from ON to OFF the input will work. If OFF is always active, verify that the contact is a N.C.
M2 Opening Limit Switch ON/OFF			M2 Opening Limit Switch Test	Contact = N.C. Default = ON If switching the command on the display from ON to OFF the input will work. If OFF is always active, verify that the contact is a N.C.
M2 Closing Limit Switch ON/OFF			M2 Closing Limit Switch Test	Contact = N.C. Default = ON If switching the command on the display from ON to OFF the input will work. If OFF is always active, verify that the contact is a N.C.
0.0V			Voltage level on the batteries	This item indicates the battery charger level
END	Exit Menu			

Note: If the Stop, Photocell 1 and Photocell 2, Edge 1 and Enge 2 contacts are not bridged in selflearning, they will be deactivated and can be reactivated through this menu, without repeating times selflearning.

RADIO TRANSMITTER SELF LEARNING WITH UNI RECEIVER ON BOARD OF CONTROL UNIT

WARNING: With Power Off Insert the receiver in the special CNR connector or strip, than switch the Power On and Program the remotes without antenna.

Receiver RF UNI accept both Rolling Plus and Fixed Code (Copy) remotes.

The first remotes programmed between rolling or fix type will set the receiver to accept one of the two for other remotes. For Rolling code remotes press twice the button to store the remote.

For Fixed code remotes press 1 time the button to store the remote. If you press twice you delete it

Notes for Remote programming:

- Only when cycle is finished and the gate is closed.

- You can store max. 2 of the below functions (START, PEDESTRIAN START...ect) .

If the control unit receives a code that has already been assigned to another function it will be updated with the new function.

RF UNI 16 users without memory
800 users with additional memory MEM

RF UNI PG 100 users fixed code
old model 800 users roll plus

RF UNI PG 100 users fixed code
new model 800 users roll plus


TX button	1	2	3	4	serial number	customer
Memory location						
0						
1						
2						
3						

RADIO CONTROL SELF-LEARNING WITH FIX RECEIVER ON BOARD

ATTENTION: Program the radio controls before connecting the antenna and inserting the receiver into the appropriate CNS connector (if available) with the FIX RF module it will be possible to use only fixed code radio transmitter.

- It will be possible to memorize up to a maximum of 16 codes (buttons), by adding the MEM memory it will be possible to memorize up to 496 different codes.


- It is possible to memorize up to 2 of the 4 functions available. If a code is received that had already been assigned to a function it will be updated with the new function.



Connect the receiver to the CNS connectors, respecting the direction in the figure .

DELETING THE TX FROM THE RECEIVER

With FIX RF modules, it will be possible to delete only the entire RX memory. Proceed as follows:



For the other functions see the menu

MENU 2
TRANSMITTERS






MENU TRANSMITTERS



QUICK START AND PROGRAMMING

A) QUICK START

Skip this step if you don't want to program a transmitter




B) PRESET INSTALLATION

ATTENTION: This procedure is potentially dangerous and must be performed only by certified electrical installers


Turn OFF the power




B Release the operators



C Manually push the leaves in half position



D Reset the mechanical lock



E Put the power ON





C) 2 MOTORS MANUAL SELFLEARNING


C.1) WITH IMPULSES *

The gate will start the following cycle: M2 CLOSING - M1 CLOSING - M1 OPENING - M2 OPENING - M2 CLOSING - M1 CLOSING. To store the respective stops during cycle, press UP or DOWN or START on each mechanical stop point of the leaf. Self-learning has been completed.


In the case of a single leaf the cycle will be CLOSING 1 - OPENING 1 - CLOSING 1.



A Both doors halfway




B M2 in closing




C M2 closed

Press UP or TX, if stored, when **M2** is closed position.




D M1 in closing




E M1 closed

Press UP or TX, if stored, when **M1** is closed position.




F M1 in opening




G M1 open

Press UP or TX, if stored, when **M1** is open position.




H M2 in opening




I M2 open

Press UP or TX, if stored, when **M2** is open position.




L M2 in closing




M M2 closed

Press UP or TX, if stored, when **M2** is closed position.



N M1 in closing



O M1 closed

Press UP or TX, if stored, when **M1** is closed position.

D) AUTOMATIC SELF-LEARNING 2 MOTORS

Make sure that, for all types of self-learning, the gate performs the following cycle: M2 CLOSING, M1 CLOSING, M1 OPENING, M2 OPENING, M2 CLOSING, M1 CLOSING. Otherwise, see the MOTOR REVERS function.

The cycle in case of single leaf will be CLOSE MOTOR 1 - OPEN MOTOR 1 - CLOSE MOTOR 1.

D.1) ENCODER

When an Encoder is installed, it is necessary to select ON in the 32-ENCODER menu.



Note: to adjust sensitivity on obstacle refer to the special menu




SELF-LEARNING starts AUTOMATICALLY. It is necessary to wait until the leaf or leaves initially start closing and then automatically complete the CLOSING - OPENING - CLOSING cycle.

D.2) ENCODER RS485

When the potentiometer is installed, it is necessary to choose between manual or automatic programming




In case of 2 motors



Push  UP

the gate will do
CLOSE - OPEN - CLOSE
then give impulse to max
opening and closing

Push  UP

Posizionare il cancello alla
max apertura e premere

Push  OK

Position the gate at maximum
closure and press


 OK

note2: In this case it is also possible to modify the parameters I.AP.M1, I.CH. 1, I.AP.M2, I.CH.M2 of + 100 impulses, to optimize the initial and the final position.

D.3) AMPEROMETRIC

(For electromechanical motors only)

This type of selflearning is possible ONLY for electromechanical operators and physical stops.



Note: to adjust sensitivity on obstacle refer to the special menu

SELF-LEARNING starts AUTOMATICALLY

At this point it is necessary to wait until the leaf or leaves start before closing and automatically complete the CLOSING - OPENING - CLOSING cycle.

D.4) WITH LIMIT-SWITCHES

1 - LIMIT SWITCH INPUT CHECK: check each limit switch on both doors by activating them before self-learning. The segment on the display will disappear when each limit switch is activated

MENU 9
PROGRAMMING

ON

SELF-LEARNING starts AUTOMATICALLY

At this point it is necessary to wait until the leaf or leaves first start closing and then automatically complete the CLOSING - OPENING - CLOSING cycle.

*REVERSE MOTOR

If the motor starts in opening, turn power off and on again, select on the display through  and  press  and put on ON,

MENU 5
REVERSE
MOTOR

or, if you have the JOLLY 3 programmer, activate the motor exchange function.


D.5) POTENTIOMETER

When the potentiometer is installed, it is necessary to select



SELF-LEARNING starts AUTOMATICALLY

It is necessary to wait until the leaf or leaves start before closing and automatically complete the cycle CLOSING - OPENING - CLOSING - OPENING with slowdown - CLOSING with slowdown.



Note: to adjust sensitivity on obstacle refer to the special menu.

The potentiometer threshold intervention is set automatically during self-learning.

It is not necessary to adjust the menu from


MENU 38
pot. from threshold
to opening 1

MENU 45
pot. slowdown
threshold closing 2

note2: With potentiometer it is also possible to do the learning by giving the pulses as described in point a in the previous paragraph. In this case it is also possible to modify the parameters I.AP. M1, I.CH. 1, I.AP.M2, I.CH.M2 of + 100 impulses, if you need to optimize the initial and the final position. Note 3: In the case of MIXED PROCEDURE (AUTOMATIC stop detection in closing and with MANUAL input in opening) the learning cycle will only be CLOSE-OPEN-CLOSE.

OPERATING FUNCTIONS

Skip this step if you work in semi-automatic logic



only after the self learning of working times with automatic logic, it will be possible to change logics into to:


A) AUTOMATIC

A start impulse opens the gate. A second impulse during the opening will not be accepted. A start impulse during closing reverses the movement.

NOTE 1: For automatic closing it is necessary to set a pause time, otherwise all the logics will be semi-automatic.



NOTE2: It is possible to choose, whether to accept or not, the start in pause, selecting in the MENU the item 8-START IN PAUSE and choosing ON or OFF. By default, the parameter is OFF.




B) SECURITY

A start impulse opens the gate. A second impulse during opening reverses the movement. A start impulse during closing reverses the movement.

NOTE 1: For automatic closing it is necessary to set a pause time, otherwise all the logics will be semi-automatic.



NOTE2: It is possible to choose, whether to accept or not, the start in pause, selecting in the MENU the item 8-START IN PAUSE and choosing ON or OFF. By default, the parameter is OFF.




C) STEP BY STEP TYPE 1

The start impulse follows the OPEN-STOP-CLOSE-STOP-OPEN logic.

NOTE 1: To have the automatic closing it is necessary to set a pause time, otherwise all the logic will be semi-automatic.



NOTE2: It is possible to choose, whether to accept or not, the start in pause, selecting in the MENU the item 8-START IN PAUSE and choosing ON or OFF. By default, the parameter is OFF.




D) STEP BY STEP TYPE 2

The start impulse follows the OPEN-STOP-CLOSE-OPEN logic.

NOTE 1: To have the automatic closing it is necessary to set a pause time, otherwise all the logic will be semi-automatic.



NOTE2: It is possible to choose, whether to accept or not, the start in pause, selecting in the MENU the item 8 - start in pause and choosing ON or OFF. By default, the parameter is OFF.



E) DEAD MAN

The gate opens as long as the START button of opening is pressed; releasing it the gate stops. The gate closes as long as the button connected to the PEDESTRIAN START is pressed; releasing it the gate stops. To execute complete opening and/or closing cycles the related pushbuttons must be constantly pressed.

F) 2 BUTTONS

One start opens, one pedestrian start closes. In opening the closing will not be accepted. In closing a start reopens, a pedestrian start (close) will be ignored.

G) E.F.O.

From MENU 136 it is possible to set the E.F.O. function, which allows emergency closing at maximum speed without taking into account any of the activated safety devices. You can reduce or increase the speed of the function

FLASHES OF ALARM

TYPE OF ALARM	NUMBER OF FLASHES	SERIES NUMBER REPETITION	FLASH SEQUENCE TYPE
COMIS	8	9	FAST i.e flashes 0.2 seconds
INVERTER FAULT 1	10	6	SLOW i.e flashes 0.5 seconds
INVERTER FAULT 2	12	6	SLOW i.e flashes 0.5 seconds
REPORT PHOTO 1 -2 CLOSING	2	5	SLOW i.e flashes 0.5 seconds
REPORT PHOTO 1 -2 OPENING	3	1	SLOW i.e flashes 0.5 seconds
REPORT OPENING COLLISION	6	11	SLOW i.e flashes 0.5 seconds
REPORT CLOSING COLLISION	6	11	SLOW i.e flashes 0.5 seconds
REPORT SAFETY EDGE	4	4	SLOW i.e flashes 0.5 seconds
SAFETY EDGE 1-2 FAULT	4	4	SLOW i.e flashes 0.5 seconds
PHOTO 1 FAULT	3	1	SLOW i.e flashes 0.5 seconds
PHOTO 2 FAULT	3	1	SLOW i.e flashes 0.5 seconds
STOP	5	2	SLOW i.e flashes 0.5 seconds
LIMIT SWITCHES FAULT	4	11	FAST i.e flashes 0.2 seconds
CYCLES ALARM	7	2	SLOW i.e flashes 0.5 seconds
if we set flashing as "ALWAYS" it will flash with a time of 0.5 seconds			
if we set flashing as "BUZZER" it will sound with a time of 0.5 seconds			
if we set flashing as "NORMAL" it flashes with a time of 0.3 seconds in closing and 0.5 seconds in opening			
if the network is missing, it flashes for 1 seconds			

UNIGATE FV - UNIGATE BR EVENTS SAVED ON DIAGNOSTIC MENU	UNIGATE FV - UNIGATE BR - ALARMS ON DISPLAY REPORTING
FOTO CLOSING	NETWORK MISSING FAULT
FOTO OPENING	24V FAULT
OBSTACLE IN OPENING	COMIS FAULT
OSTACLE IN CLOSING	SAFETY EDGE 1 FAULT
EDGE 1 FAULT	SAFETY EDGE 2 FAULT
EDGE 2 FAULT	FOTO 1 FAULT
STOP	FOTO 2 FAULT
MAITENANCE	LIMIT SWITCH FAULT
NETWORK MISSING	BATTERY FAULT
LIMIT SWITCH	POTENTIOMETER FAULT
ALWAYS CLOSE	POTENTIOMETER 1 DIRECTION FAULT
EMERGENCY	POTENTIOMETER 2 DIRECTION FAULT
INVERTER 1	SERIAL INVERTER 1 FAULT
INVERTER 2	SERIAL INVERTER 2 FAULT
INVERTER FROM MODULE 1	SERIAL INVERTER FROM MODULE 1 FAULT
INVERTER FROM MODULE 2	SERIAL INVERTER FROM MODULE 2 FAULT
COMIS	INVERTER 1 FAULT (FOLLOWED BY ERROR CODE)
	INVERTER 2 FAULT (FOLLOWED BY ERROR CODE)
	MODULE 1 TYPE ERROR
	MODULE 2 TYPE ERROR
	PASSWORD ERROR

INVERTER ERRORS	ERRORS SUM TABLE * NUMBERS SUMS FOLLOWS THE ORDER OF THE COLUMNS ASIDE	UNIGATE FV - UNIGATE BR -ALARMS ON DISPLAY REPORTING
2	6 - 10 - 18 - 66 - 258 - 514	OVER VOLTAGE
4	12 - 20 - 68 - 260 - 516	UNDER VOLTAGE
8	24 - 72 - 264 - 520	OVER TEMPERATURE MODULE INVERTER
16	80 - 272 - 528	OVER TEMPERATURE MODULE INVERTER
64	320 - 576	OVER CURRENT
256 (only on FV module)	768	COMMUNICATION FAULT
512 (only on FV module)		SHUT DOWN MODULE

*In case of Errors, the display shows the Error Sum.

Example: if the Error 260 is shown, it will be the sum of errors "4" + "256"

UNIGATE FV EVENTS SAVED ON DIAGNOSTIC MENU	UNIGATE FV ALARMS ON DISPLAY REPORTING
FAULT POTENTIOMETER 1-MECHANICAL	FAULT ROTARY ENCODER 1 - RS484
FAULT POTENTIOMETER 2-MECHANICAL	FAULT ROTARY ENCODER 2 - RS484
FAULT POTENTIOMETER 1 VOLTAGE	FAILURE POWER SUPPLY OR VOLTAGE ERROR ON ROTARY ENCODER 1 - RS484
FAULT POTENTIOMETER 2 VOLTAGE	FAILURE POWER SUPPLY OR VOLTAGE ERROR ON ROTARY ENCODER 2 - RS484
FAULT 1 - RS485	NON COMMUNICATION BETWEEN ROTARY ENCODER 1 - RS485 AND SCHEDA RS 485
FAULT 2 - RS485	NON COMMUNICATION BETWEEN ROTARY ENCODER 2 - RS485 AND SCHEDA RS 485
FAULT RS 485 - SERIAL	NON COMMUNICATION BETWEEN RS485 AND UNIGATE

UNIGATE FV - ALARMS FAULT ON FLASHING LAMP	ALARMS FAULT ON FLASHING LAMP
5 FLASHING FOR 6 TIMES IN SLOW SEQUENCE	FAULT ROTARY ENCODER 1 - RS484 O FAULT RS485 SERIAL
5 FLASHING FOR 6 TIMES IN FAST SEQUENCE	FAULT ROTARY ENCODER 2 - RS484

MENU FUNCTIONS TABLE - UNIGATE

LEGEND

INVERTER - FUNCTION AVAILABLE ON MODEL UNIGATE WITH INVERTER MODULE (1I - 2I - 1I BIG - 2I BIG)

2PM - FUNCTION AVAILABLE ON MODEL UNIGATE WITH 2PM MODULE

BR - FUNCTION AVAILABLE ON MODEL UNIGATE WITH BR MODULE

ALL - COMMON FUNCTIONS - AVAILABLE ON ALL UNIGATE MODELS

MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE		
1	LANGUAGE	Italiano	Italian	ALL	English			
		English	English					
		Français	French					
		Español	Spanish					
		Dutch	Dutch					
2	TRANSMITTERS	Start	Start	ALL	Start Partial opening			
		Partial opening	Partial opening					
		External module	External module					
		Stop	Stop					
		Relay 1	To Activate Relay 1 for 3 seconds. This function requires menu "Relay 1" set on "TX Relay"					
		Relay 2	To Activate Relay 2 for 3 seconds. This function requires menu "Relay 2" set on "TX Relay"					
		Bistable Stop	Pressed once, it stops the gate. Pressed twice, it reactivates the START input					
		Latch opening	One impulse opens and keep open. A second impulse restore the movement					
		Latch closing	One impulse closes and keep closed. A second impulse restore the movement					
		Unlock	To store a command for unlocking the electric brake					
		Delete a transmitter	To delete a single transmitter (TX)					
		Move to EEP	To transfer the transmitters stored on the control unit to the external EEPROM (MEM), if connected					
		Clear memory	To delete the full TX memory on the receiver					
		End	To exit the menu "transmitters"					
3	MOTOR	1- Hydraulic	Hydraulic operators - Series I (INVERTER)	INVERTER 2PM	Hydraulic			
		2- Sliding	Sliding operators - Series I (INVERTER) (Lepus FAST operator too)					
		3- Reversible Sliding	Reversible sliding operators - Series I (INVERTER)					
		4- Electromechanic swing	Electromechanic swing operators - Series I (INVERTER)					
		5- Three-phase - Bollards	Three-phase operators and Bollards Series I BIG (INVERTER with BIG module)					
		7- Barrier	Barriers - Series I (INVERTER)	INVERTER				
		8- BIG Fast BIG Super Fast 4LS	Sliding operators - Series I BIG (INVERTER with BIG module)					
		9- BIG	Sliding operators - Series I BIG (INVERTER with BIG module)					
		10- JOINT 4LS	Hydraulic operator with 4 limit switch Series I (INVERTER)					
		60- BIG RS 485	Sliding operators - Series I BIG (INVERTER with BIG module)					
		61- SEAGEAR RS 485	Sliding operators - Series I BIG (INVERTER with BIG module)					
		62- PORTA RAPIDA	Electromechanic operator - Series I (INVERTER)					
		50- HALF TANK BR	Hydraulic operator - Series BR (BRUSHLESS)					
		51- SURF BR	Electromechanic swing operator - Series BR (BRUSHLESS)					
		52- SATURN BR	Electromechanic operator - Series BR (BRUSHLESS)					
		56- COMPACT BR	Hydraulic operator - Series BR (BRUSHLESS)					

MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
4	GATES NUMBER	From 1 to 2	To set the number of motors to be managed	INVERTER BR	1	
		From 1 to 4		2PM	2	
5	REVERSE MOTOR	On	To reverse the opening with the closing or vice-versa (both motors and limit-switches are reversed)	ALL	Off	
		Off	Off			
6	LOGIC	Automatic	Automatic	ALL	Auto- matic	
		Open-stop-close-stop-open	Step by step type 1			
		Open-stop-close-open	Step by step type 2			
		2 button	Two buttons			
		Safety	Safety			
		Dead man	Dead man			
7	PAUSE TIME	Off	OFF (semi-automatic logics)	ALL	Off	
		1 240	Setting from 1 second to 4 minutes			
8	START IN PAUSE	Off	The Start command is not accepted during pause	ALL	Off	
		On	The Start command is accepted during pause			
9	PROGRAMMING	Off On	To start the working times self-learning	ALL	Off	
10	TEST START	Off On	To give a Start command for testing the automation	ALL	Off	
11	BEAM LENGTH	3m - 4m - 5m - 6m 7m - 7,5m - 8m	This menu will be shown only if the option 7-Barrier is set in the menu 3-MOTORS. It allows to choose the beam length (values in meters)	INVERTER BR	----	
12	SLOWDOWN LIMIT SWITCH	Off On	This menu will be shown only if the option 5-Threephase/Bollards is set in the menu 3-MOTORS. It allows to activate the slowdown limit switch <u>on bollards</u>	INVERTER	Off	
13	LATCH PAUSE	Off On	If "ON" the operator complies with the pause time set when the function "LATCH OPENING" is disabled. When "OFF" the pause time set is not respected	INVERTER BR	Off	
14	RESET	A count-down of 5 seconds will start by holding the UP button; at its end "INIT" will appear on the display as confirmation of the control board reset				
192	MOVE GATE 1 *	Allows the movement of the gate for tests or specific positioning in a temporary "dead man" mode HOLDING UP PRESSED = OPEN HOLDING DOWN PRESSED = CLOSE		INVERTER BR	----	
193	MOVE GATE 2 *	Allows the movement of the gate for tests or specific positioning in a temporary "dead man" mode HOLDING UP PRESSED = OPEN HOLDING DOWN PRESSED = CLOSE		INVERTER BR	----	
* The command is accepted only at the end of the cycle or after a STOP; it is not accepted during the cycle and during the pause						
15	END	Press OK to return to the display of the firmware version and to the one of inputs state				
16	SPECIAL MENU	Press OK to enter the special menu				



SPECIAL MENU

PRESS UP AND DOWN FOR 5 SECONDS AT THE SAME TIME TO ENTER OR TO EXIT THE SPECIAL MENU

LEGEND

INVERTER - FUNCTION AVAILABLE ON MODEL UNIGATE WITH INVERTER MODULE (1I - 2I - 1I BIG - 2I BIG)

2PM - FUNCTION AVAILABLE ON MODEL UNIGATE WITH 2PM MODULE



BR - FUNCTION AVAILABLE ON MODEL UNIGATE WITH BR MODULE

ALL - COMMON FUNCTIONS - AVAILABLE ON ALL UNIGATE MODELS

SPECIAL MENU FUNCTIONS TABLE - UNIGATE

SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
17	OPENING SPEED 1	10 100	Speed in opening Motor 1	INVERTER	80	
		30 100		BR		
18	CLOSING SPEED 1	10 100	Speed in closing Motor 1	INVERTER	80	
		30 100		BR		
19	OPENING SPEED 2	10 100	Speed in opening Motor 2	INVERTER	80	
		30 100		BR		
20	CLOSING SPEED 2	10 100	Speed in closing Motor 2	INVERTER	80	
		30 100		BR		
21	SLOWDOWN SPEED IN OPENING 1	From 10% to 60% of the maximum speed	slowdown speed in opening Motor 1	INVERTER BR	30	
22	SLOWDOWN SPEED IN CLOSING 1	From 10% to 60% of the maximum speed	slowdown speed in closing Motor 1	INVERTER BR	30	
23	SLOWDOWN SPEED IN OPENING 2	From 10% to 60% of the maximum speed	slowdown speed in opening Motor 2	INVERTER BR	30	
24	SLOWDOWN SPEED IN CLOSING 2	From 10% to 60% of the maximum speed	slowdown speed in closing Motor 2	INVERTER BR	30	
25	LEARNING SPEED	10% 100 %	To adjust the time self-learning speed. This parameter can change according to the motor type set	INVERTER	50	
		20% 100 %		BR		
26	LEAF DELAY IN OPENING	Off 6 Total	Adjustable from Off to 6 seconds to "Total" (if on "Total" the Motor2 will start opening only after the Motor1 has completed the movement)	INVERTER BR	1,5	
		Off 6	Adjustable from OFF (disabled) to 6 seconds	2PM		
27	LEAF DELAY IN CLOSING	Off 20 Total	Adjustable from Off to 20 seconds to "Total" (if on "Total" the Motor1 will start closing only after the Motor2 has completed the movement)	INVERTER BR	2,5*	
		Off 20	Adjustable from OFF (disabled) to 20 seconds	2PM		
28	OPENING TORQUE 1	50% 100 %	Motor 1 opening torque: by increasing the torque, more strength will be required to execute the inversion in case of obstacle	INVERTER 2PM	100%	
		5% 100 %		BR		
29	CLOSING TORQUE 1	50% 100 %	Motor 1 closing torque: by increasing the torque, more strength will be required to execute the inversion in case of obstacle	INVERTER 2PM	100%	
		5% 100 %		BR		
30	OPENING TORQUE 2	50% 100 %	Motor 2 opening torque: by increasing the torque, more strength will be required to execute the inversion in case of obstacle	INVERTER 2PM	100%	
		5% 100 %		BR		
31	CLOSING TORQUE 2	50% 100 %	Motor 2 closing torque: by increasing the torque, more strength will be required to execute the inversion in case of obstacle	INVERTER 2PM	100%	
		5% 100 %		BR		

SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
32	ENCODER	On	ON = Encoder enabled OFF = Encoder disabled <i>(when OFF, the working times learnt are only shown)</i>	ALL	It depends on motor	
		Enc ABC	To enable the rotary Encoder for the management of the brushless operator and its position	BR	It depends on motor	
	47 ENCODER PAR.1	xxx.	Impulses read by Encoder during operation (Motor1)			
	48 ENCODER TOT. 1	xxx.	Impulses stored during programming (Motor 1)			
	49 ENCODER PAR.1	xxx.	Impulses read by Encoder during operation (Motor2)			
	50 ENCODER TOT. 2	xxx.	Impulses stored during programming (Motor 2)			
32	ENCODER	Potentiometer	To enable the reading of the potentiometer	ALL	Off	
		RS 485	To enable the reading of the absolute rotative Encoder	INVERTER BR		
	51 I.PAR.M1 *	-----	To show the current position of the potentiometer on the leaf moved by Motor 1 . This parameter is useful to see if the potentiometer is correctly read			
	52 I.AP.M1	From the value learnt to ± 100 pulses	To show the impulses stored by the control unit when the leaf moved by Motor 1 is fully open			
	53 I.CH.M1	From the value learnt to ± 100 pulses	To show the impulses stored by the control unit when the leaf moved by Motor 1 is fully close			
	54 I.PAR.M2 *	-----	To show the current position of the potentiometer on the leaf moved by Motor 2 . This parameter is useful to see if the potentiometer is correctly read			
	55 I.AP.M2	From the value learnt to ± 100 pulses	To show the impulses stored by the control unit when the leaf moved by Motor 2 is fully open			
	56 I.CH.M2	From the value learnt to ± 100 pulses	To show the impulses stored by the control unit when the leaf moved by Motor 2 is fully close			
* While the partial impulses are displayed, it is possible to OPEN (by pressing UP) or CLOSE (by pressing DOWN) the corresponding operator to verify the correct reading of the potentiometer after installation or simply for checking						
32	ENCODER	Off	ON = Encoder enabled OFF = Encoder disabled <i>(when OFF, the working times learnt are only shown)</i>	ALL	Off	
	65 OPENING TIME M1	xxx.s	To display the learnt value during the working times self learning, in opening and closing (Motor 1) . With UP or DOWN it is possible to increase or reduce the working times			
	66 CLOSING TIME M1	xxx.s				
	67 OPENING TIME M2	xxx.s	To display the learnt value during the working times self learning, in opening and closing (Motor 2) . With UP or DOWN it is possible to increase or reduce the working times			
	68 CLOSING TIME M2	xxx.s				
33	OPENING SENSITIVITY MOTOR 1	10% (Fast intervention) 99% (Slow intervention)	To adjust the Encoder or Potentiometer intervention time on Motor 1 in opening	ALL	Off	
		Off (Intervention excluded)	Disabled			
34	CLOSING SENSITIVITY MOTOR 1	10% (Fast intervention) 99% (Slow intervention)	To adjust the Encoder or Potentiometer intervention time on Motor 1 in closing	ALL	Off	
		Off (Intervention excluded)	Disabled			
35	OPENING SENSITIVITY MOTOR 2	10% (Fast intervention) 99% (Slow intervention)	To adjust the Encoder or Potentiometer intervention time on Motor 2 in opening	ALL	Off	
		Off (Intervention excluded)	Disabled			
36	CLOSING SENSITIVITY MOTOR 2	10% (Fast intervention) 99% (Slow intervention)	To adjust the Encoder or Potentiometer intervention time on Motor 2 in closing	ALL	Off	
		Off (Intervention excluded)	Disabled			

SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
37	SLOWDOWN SENSITIVITY MOTOR	10% (Fast intervention) 99% (Slow intervention)	To adjust the amperometric sensitivity in slowdown Function available only on electro-mechanic operators	ALL	Off	
		With potentiometer	To set the inversion time in slow-down from 0 to 5 seconds (= 99%) - Only with potentiometer enabled		30%	
38	POTENTIOMETER THRESHOLD OPENING 1	1 1000 (only if the Menu 32-Encoder is set on "Potentiometer")	To adjust the threshold of the potentiometer intervention. This parameter self-determines during the working times learning but can also be adjusted later, on the condition that the set value is higher than the value shown in VP1 or VP2 (instantaneous speed values which can be shown by accessing the DEBUG menu). NOTE: The lower the threshold value, the slower will be the response of the potentiometer.	ALL	----	
39	POTENTIOMETER THRESHOLD CLOSING 1					
40	POTENTIOMETER THRESHOLD OPENING 2					
41	POTENTIOMETER THRESHOLD CLOSING 2					
42	POTENTIOMETER SLOWDOWN THRESHOLD OPENING 1	1 100 (only if the Menu 32-Encoder is set on "Potentiometer")	To adjust the threshold of the potentiometer intervention in slowdown. By default this value is set on 10. but can be manually increased on the condition that the set value is higher than the value shown in VP1 or VP2 (instantaneous speed values which can be shown by accessing the DEBUG menu)	ALL	15	
43	POTENTIOMETER SLOWDOWN THRESHOLD CLOSING 1					
44	POTENTIOMETER SLOWDOWN THRESHOLD OPENING 2					
45	POTENTIOMETER SLOWDOWN THRESHOLD CLOSING 2					
46	CLOSING INVERSION	Total	In case of obstacle or safety edge it totally reverses the movement during closing. If active, the automatic reclosing will be attempted for 5 times	ALL	Total	
		Partial	In case of obstacle, safety edge or potentiometer, it partially reverses direction (of about 30 cm) then stops			
For menu 47 and 50 see menu 32-Encoder = On						
For menu from 51 to 56 see menu 32-Encoder = Potentiometer						
57	WORKING CURRENT 1 Ampere	To display the absorbed current during Motor 1 working	INVERTER BR	----	
58	WORKING CURRENT 2 Ampere	To display the absorbed current during Motor 2 working	INVERTER BR	----	
59	OPENING SLOWDOWN 1	0 50	From 0% to 50% of the stroke (0% = slowdown excluded)	ALL	30	
60	CLOSING SLOWDOWN 1	0 50	From 0% to 50% of the stroke (0% = slowdown excluded)	ALL	30	
61	OPENING SLOWDOWN 2	0 50	From 0% to 50% of the stroke (0% = slowdown excluded)	ALL	30	
62	CLOSING SLOWDOWN 2	0 50	From 0% to 50% of the stroke (0% = slowdown excluded)	ALL	30	
63	DECELERATION	0 % 100% 	To adjust the change from normal speed to slowdown speed	ALL	It depends on motor	
64	ACCELERATION	0,1 s 5 s 	Acceleration ramp. To adjust the motor start	ALL	It depends on motor	
For menu from 65 to 68 see menu 32-Encoder = Off (They are visible even with 32-Encoder set ON)						

SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
69	ANTI OVERLAP	Off	To disable the anti-overlapping control of the leaves allowing their separate control	ALL	Off	
		On	To enable the anti-overlapping control of the leaves			
70	OPENING POSITION RECOVERY	0 20 seconds (only if 32-Encoder is OFF)	To retrieve the inertia of the motor in opening after the Stop or the reversing	ALL	It depends on motor	
71	CLOSING POSITION RECOVERY	0 20 seconds (only if 32-Encoder is OFF)	To retrieve the inertia of the motor in closing after the Stop or the reversing	ALL	It depends on motor	
72	OPENING TOLERANCE MOTOR 1	0% 100%	To adjust the Motor 1 tolerance between the stop and the obstacle, in opening	ALL	20%	
73	CLOSING TOLERANCE MOTOR 1	0% 100%	To adjust the Motor 1 tolerance between the stop and the obstacle, in closing	ALL	20%	
74	OPENING TOLERANCE MOTOR 2	0% 100%	To adjust the Motor 2 tolerance between the stop and the obstacle, in opening	ALL	20%	
75	CLOSING TOLERANCE MOTOR 2	0% 100%	To adjust the Motor 2 tolerance between the stop and the obstacle, in closing	ALL	20%	
76	PUSHING STROKE	Time Pushing Off - 3 sec Stroke	Before opening, the motor starts in closing for the time set, in order to simplify the lock release	ALL	Off	
		Repeat Lock Release Off – On	If ON , the lock will be released both before and after the pushing stroke			
		End				
77	LOCK TIME	Off 5	To adjust the lock release time from 0 to 5 seconds	ALL	3	
78	LOCK	Only opening	Lock enabled only before opening	ALL	Only opening	
		Only closing	Lock enabled only before closing			
		Opening and closing	Lock enabled before opening and closing			
79	ANTI INTRUSION	Only opening	If the gate is forced manually, the control unit starts the motor and restores the state of the gate before forcing (function only available if limit switches are installed)	ALL	Off	
		Only closing				
		Opening and closing				
		Off				
80	PUSHOVER	Off	The gate leaf makes an extra movement at the maximum torque to ensure the tightening of the gate	ALL	Off	
		Opening and closing				
		Only closing				
		Only opening				
81	PERIODICAL PUSHOVER	Off 8h (only if 80-Pushover is ON)	To activate the repetition of the pushover function at a distance of time adjustable from 0 to 8 hours, at hourly intervals	ALL	Off	
82	MOTOR RELEASE	Opening 1 Off - 3 s	If different from OFF, the operator slightly reverses its direction at the end of the cycle	ALL	It depends on motor	
		Closing 1 Off - 3 s				
		Opening 2 Off - 3 s				
		Closing 2 Off - 3 s				
		End				
83	EXTRA TIME	Opening1 Off - 10s	If the limit switches are installed, it is possible to add an extra time (max. 10 seconds) to the movement of the operators after the reading of the limit switches	INVERTER BR	1.0 s	
		Closing 1 Off - 10s				
		Opening2 Off - 10s				
		Closing 2 Off - 10s				
		EXIT				
		0.0 s 10 s		2PM		

SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
85	PRE-FLASHING	<i>Only closing</i>	To enable the pre-flashing only before closing (to access: push DOWN button when 0.0 value is shown)	ALL	0.0 s	
		0.0 5.0 s	To set the pre-flashing duration			
86	FLASHING LIGHT	<i>Normal</i>	Normal	ALL	Normal	
		<i>Light</i>	Warning lamp function			
		<i>Always</i>	Always ON			
		<i>Buzzer</i>	Buzzer			
87	FLASHING LIGHT AND TIMER	<i>Off</i>	The flashing light will be OFF with enabled timer and open gate	ALL	Off	
		<i>On</i>	The flashing light will be ON with enabled timer and open gate			
88	COURTESY LIGHT	<i>Off</i>	Disabled	ALL	In cycle	
		1 240	Adjustable from 1 second to 4 minutes			
		<i>In cycle</i>	Courtesy light only in cycle			
89	TRAFFIC LIGHT RESERVATION	<i>Off On</i>	To get the priority in entry or exit. Available by the use of the partial opening contact	ALL	Off	
90	PARTIAL OPENING	5% 100%	Adjustable from 5% to 100%	ALL	50%	
91	PARTIAL PAUSE	<i>= Start</i>	The pause in partial opening is the same as in total opening	ALL	= Start	
		<i>Off</i>	Disabled			
		1 240	Adjustable from 1 second to 4 minutes			
92	TIMER	<i>Off</i>	To turn the selected input into an input to which connect an external clock	ALL	Off	
		<i>On photo2</i>				
		<i>On partial input</i>				
		<i>Clock</i>				
93	FIRE SWITCH	<i>Off</i>	Disabled	ALL	Off	
		<i>On Photo2</i>	Function enabled on the Photocell 2 input			
		<i>On partial input</i>	Function enabled on the partial opening Start input			
94	24V AUX (Max. 500 mA)	<i>Always</i>	AUX output always powered	ALL	Always	
		<i>In cycle</i>	AUX output powered only during cycle			
		<i>Opening</i>	AUX output powered only during opening			
		<i>Closing</i>	AUX output powered only during closing			
		<i>In pause</i>	AUX output powered only during pause			
		<i>Phototest</i>	AUX output powered for safety devices testing			
		<i>In cycle and phototest</i>	AUX output powered during cycle only and for safety devices testing			
		<i>In cycle and pause</i>	AUX output powered during cycle and during pause			
		<i>Courtesy light (connected through relay)</i>	AUX output allows the connection of an additional relay for the management of an additional light which will work as per Menu-88 settings			
		<i>Barrier and Bollard LED lights</i>	Closed operator - the light is switched-on Open operator - the light is switched-off Moving operator - the light blinks			
		<i>Open gate warning light (connected through relay)</i>	1 flash per second during opening 2 flashes per second during closing Steady lit in "Stop" or "Open" status			

SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
95	PHOTO-TEST	<i>Photo 1</i>	Self-test enabled only on photocell 1	ALL	Off	
		<i>Photo 2</i>	Self-test enabled only on photocell 2			
		<i>Photo 1 and 2</i>	Self-test enabled on photocells 1 and 2			
		<i>Off</i>	Disabled			
96	SAFETY EDGE SELF-TEST	<i>Edge 1</i>	Self-test enabled only on safety edge 1	ALL	Off	
		<i>Edge 2</i>	Self-test enabled only on safety edge 2			
		<i>Edges 1 and 2</i>	Self-test enabled on safety edges 1 and 2			
		<i>Off</i>	Disabled			
97	PHOTOCELL 1	<i>Closing</i>	If the photocell is occupied during closing, the gate reverses the movement; If the photocell is occupied during the pause, it prevents the gate reclosing	ALL	Closing	
		<i>Opening and closing</i>	If the photocell is occupied during opening or closing, it stops the gate movement; when the photocell is released, the movement continues			
		<i>Stop</i>	If the photocell is occupied before the Start input, the Start will be ignored. If the photocell is occupied after the Start input, the photocell will be ignored. If the photocell is occupied during closing, the gate will reopen			
		<i>Stop and close</i>	If the photocell is occupied during closing, it stops the gate movement; when released, the closing movement continues			
		<i>Close</i>	The photocell stops the gate until it is occupied in both opening and closing; when released, the photocell gives a closing command (the gate closes one second after the photocell release)			
		<i>Closing Pause reloading</i>	If the photocell is occupied during the pause, it recharges the same pause time set. If the photocell is occupied in closing, it reverses the gate movement			
		<i>Opening and Closing Pause reloading</i>	If the photocell is occupied during the pause, it recharges the same pause time set. If the photocell is occupied during the closing, it reverses the gate movement; If the photocell is occupied during the opening, it stops the gate and when released, the opening movement continues			
		<i>Shadow loop (For 2PM module: not active if menù-121 is on "Photo 1 10K")</i>	When the gate is open, the shadow loop prevents the reclosing until it is occupied. The Shadow loop is switched off during closing			
		<i>Delete pause time</i>	If the photocell is occupied during opening, pause or closing, the gate reopens completely and closes without observing the pause time set			
		<i>Shadow loop RP (pause reloading) (For 2PM module: not active if menù-121 is on "Photo 1 10K")</i>	When the gate is open, the shadow loop prevents the reclosing until it is occupied. When released, the gate repeats the pause time set, then it closes. The Shadow loop is switched off during closing			

SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
98	PHOTOCELL 2	<i>Closing</i>	If the photocell is occupied during closing, the gate reverses the movement; If the photocell is occupied during the pause, it prevents the gate reclosing	ALL	Opening and closing	
		<i>Opening and closing</i>	If the photocell is occupied during opening or closing, it stops the gate movement; when the photocell is released, the movement continues			
		<i>Stop</i>	If the photocell is occupied before the Start input, the Start will be ignored. If the photocell is occupied after the Start input, the photocell will be ignored. If the photocell is occupied during closing, the gate will reopen			
		<i>Stop and close</i>	If the photocell is occupied during closing, it stops the gate movement; when released, the closing movement continues			
		<i>Close</i>	The photocell stops the gate until it is occupied in both opening and closing; when released, the photocell gives a closing command (the gate closes one second after the photocell release)			
		<i>Opening Pause reloading</i>	If the photocell is occupied during the pause, it recharges the same pause time set. If the photocell is occupied during the opening, the gate stops and when released, the movement continues			
		<i>Pause reload Photo closing</i>	If the photocell is occupied during the pause, it recharges the pause time set. If the photocell is occupied during closing, the gate reverses the movement			
		<i>Opening and Closing Pause reloading</i>	If the photocell is occupied during the pause, it recharges the same pause time set. If the photocell is occupied during the closing, it reverses the movement; If the photocell is occupied during the opening, it stops the gate and when released, the opening movement continues			
		<i>Shadow loop (For 2PM module: not active if menù-122 is on "Photo 2 10K")</i>	When the gate is open, the shadow loop prevents the reclosing until it is occupied. The Shadow loop is switched off during closing			
		<i>Delete pause time</i>	If the photocell is occupied during opening, pause or closing, the gate reopens completely and closes without observing the pause time set			
99	PHOTO OFF IN CLOSING	<i>Shadow loop PR (pause reloading) (For 2PM module: not active if menù-122 is on "Photo 2 10K")</i>	When the gate is open, the shadow loop prevents the reclosing until it is occupied. When released, the gate repeats the pause time set, then it closes. The Shadow loop is switched off during closing	INVERTER	0%	
		<i>Stop and open</i>	If the photocell is occupied during opening, the gate will stop; when released, the gate continues the opening movement. The photocell is ignored during closing			
		0% 50%	In closing, this function excludes the photocell reading for the space percentage set			

SPECIAL MENU		SET		DESCRIPTION	MODEL	DEFAULT	NOTE
100	SAFETY EDGE 1	Normal		Normal N.C. contact	ALL	Normal	
		8K2 N.C.		Safety edge protected by a 8K2 resistor enabled			
		8K2 N.C. Double		Two safety edges protected by 8K2 resistor enabled			
		8K2 RES		Resistive edge protected by 8K2 resistor enabled			
		8K2 RES Double		Two resistive edges protected by 8K2 RES enabled			
101	SAFETY EDGE 2	Normal		Normal N.C. contact	ALL	Normal	
		8K2 N.C.		Safety edge protected by a 8K2 resistor enabled			
		8K2 N.C. Double		Two safety edges protected by 8K2 resistor enabled			
		8K2 RES		Resistive edge protected by 8K2 resistor enabled			
		8K2 RES Double		Two resistive edges protected by 8K2 RES enabled			
102	SAFETY EDGE 1 DIRECTION	Opening and closing		Safety edge enabled in opening and closing	ALL	Opening and Closing	
		Only opening		Safety edge enabled only in opening			
		Only closing		Safety edge enabled only in closing			
103	SAFETY EDGE 2 DIRECTION	Opening and closing		Safety edge enabled in opening and closing	ALL	Opening and Closing	
		Only opening		Safety edge enabled only in opening			
		Only closing		Safety edge enabled only in closing			
104	SELECT LIMIT SWITCH	N. C.		Limit switch type N.C. (Normally Closed) Example: inductive limit switch or with lever	INVERTER	N.C.	
		Ext		Limit switch connected on the external interface for 4 cams limit switches			
		N.O.		Limit switch type N.O. (Normally Open) Example: magnetic limit switch			
		Automatic		Automatic detection of the limit switch	2PM	Automatic	
		Opening only		Limit switch enabled only in opening			
		Closing only		Limit switch enabled only in closing			
		Ext		Limit switch connected on the external interface for 4 cams limit switches			
		Motor internal		To be enabled if the operator is equipped with an inner limit switch that stops the motor phase			
105	MASTER-SLAVE	Master		To set the control unit as MASTER on applications with two operators in master/slave mode	INVERTER	Off	
		Slave		To set the control unit as SLAVE on applications with two operators in master/slave mode			
		Off		Disabled			
106	DIAGNOSTICS	1	10	To display the last event (See alarms table)	ALL	----	
107	MAINTENANCE CYCLES	100	240000	Adjustable from 100 to 240000 cycles	ALL	100000	
108	PERFORMED CYCLES	0	240000	To display the executed cycles. Hold pressed OK to reset the cycles	ALL	0	
109	THERMOMETER	xx °C	(xx °C)	To display the temperature if a probe is connected on GP1 or GP2 (and the menus 130 and 131 are set on "Thermometer") The connection of up to two temperature probes is allowed; (display will show both temperatures detected)	ALL	Off	

SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
110	LOWER THRESHOLD TEMPERATURE	<i>From -20° to +50°</i>	To adjust the temperature threshold of the oil heater probe activation (<i>This menu is shown only if the menu 109-Thermometer is set to ON</i>)	ALL	-10°	
111	UPPER THRESHOLD TEMPERATURE	<i>From -20° to +50°</i>	To adjust the temperature threshold of the oil heater probe deactivation (<i>This menu is shown only if the menu 109-Thermometer is set to ON</i>)	ALL	0°	
112	PASSWORD	<i>Note: "0000" setting is not allowed</i>	To enter a password for blocking the control unit parameters modification	ALL	----	
113	EMERGENCY	<i>Off</i>	Disabled	ALL	<i>Off</i>	
		<i>Emergency</i>	In case of power failure and with batteries connected and charged, the gate opens completely and remains open until the power is restored	ALL		
		<i>Last opening</i>	In case of power failure, as soon as the battery charge drops below 22V, the gate opens one last time and remains open until the power is restored	ALL		
		<i>Last closing</i>	In case of power failure, as soon as the battery charge drops below 22V, the gate closes one last time and remains closed until the power is restored	ALL		
115	DECELERATION RAMP	0,1 s 5s	Deceleration management in case of inversion or Stop command	INVERTER BR	0,5 s	
116	REPEAT LEAF DELAY	<i>On Off</i>	In case of a STOP command when the gate is on its halfway, the leaves will repeat the "leaf delay" set on	ALL	<i>On</i>	
117	ALWAYS CLOSE	<i>Off 240 seconds</i>	In case of power failure, if the gate has been manually open, it closes only after the set time has elapsed (<i>from 0 to 240 seconds</i>) as soon as the power is restored	ALL	<i>Off</i>	
118	LATCH	<i>Off</i>	Disabled	ALL	<i>Off</i>	
		<i>Opening</i>	The gate opens and stay open till a new Start input. <i>The latch function uses the "Safety Edge 1" N.O. input (Safety Edge 1 function is so disabled)</i>	ALL		
		<i>Closing</i>	The gate closes and stay closed till a new Start input. <i>The latch function uses the "Safety Edge 2" N.O. input (Safety Edge 2 function is so disabled)</i>	ALL		
		<i>Opening and closing</i>	To enables both the opening and closing functions above described. <i>The latch function uses the "Safety Edge 1" and "Safety Edge 2" N.O. inputs (both safety edges are so disabled)</i>	ALL		
119	DISPLAY WRITING SPEED	<i>From 30% to 100%</i>	See Note 2 at the end of the table	ALL	80%	
120	BASIC MENU	Press OK to exit the special menu. The special menu switches off automatically after 20 minutes				
121	PHOTO 1 TYPE	<i>Normal</i>	Standard photocell without 10K control	ALL	<i>Normal</i>	
		<i>Photo 1 10K</i>	Photocell with 10K control			
		<i>Photo 1 10K DOUBLE</i>	Double photocell with 10K control			
122	PHOTO 2 TYPE	<i>Normal</i>	Standard photocell without 10K control	ALL	<i>Normal</i>	
		<i>Photo 2 10K</i>	Photocell with 10K control			
		<i>Photo 2 10K DOUBLE</i>	Double photocell with 10K control			
123	DATE AND TIME	<i>Mon - Sun dd/mm/yyyy Time</i>	To set the day, the date and the time for the management of the programmed openings. <i>(Only with full charge buffer battery)</i>	ALL	----	

SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
124	CLOCK 1	Opening time	To set a first time band in which keeping the gate open. It is possible to set, in order: opening time, closing time and the days on which you want to open and keep the gate open	ALL	Off	
		Closing time				
		Days				
		Modify	To modify the pre-set time and day			
		Exit	Exit from menu			
125	CLOCK 2	Opening time	To set a second time band in which keeping the gate open. It is possible to set, in order: opening time, closing time and the days on which you want to open and keep the gate open	ALL	Off	
		Closing time				
		Days				
		Modify	To modify the pre-set time and day			
		Exit	Exit from menu			
126	CLOCK 3	Opening time	To set a third time band in which keeping the gate open. It is possible to set, in order: opening time, closing time and the days on which you want to open and keep the gate open	ALL	Off	
		Closing time				
		Days				
		Modify	To modify the pre-set time and day			
		Exit	Exit from menu			
127	CLOCK 4	Opening time	To set a fourth time band in which keeping the gate open. It is possible to set, in order: opening time, closing time and the days on which you want to open and keep the gate open	ALL	Off	
		Closing time				
		Days				
		Modify	To modify the pre-set time and day			
		Exit	Exit from menu			
130	GP1	Off	Disabled	ALL	Off	
		Open	To connect an opening button that allows the automation operating in "Dead Man" logic. The button will only work when the gate is closed or after a Stop command			
		Emergency open	To connect an opening button that allows the automation operating in "Dead Man" logic. The button will only work in case of safety devices failure or in case of stuck Start button			
		Thermometer	To connect a temperature probe for the detection of an external temperature which will be shown on the display by accessing menu 109-THERMOMETER (<i>i.e. probe for detection of hydraulic motor oil temperature</i>)			
		Cage	To control the Motor 1 only if the Motor 2 is closed	INVERTER		
131	GP2	Off	Disabled	ALL	Off	
		Close	To connect a closing button that allows the automation operating in "Dead Man" logic. The button will only work when the gate is closed or after a Stop command			
		Emergency close	To connect an closing button that allows the automation operating in "Dead Man" logic. The button will only work in case of safety devices failure or in case of stuck Start button			
		Thermometer	To connect a temperature probe for the detection of an external temperature which will be shown on the display by accessing menu 109-THERMOMETER (<i>i.e. probe for detection of hydraulic motor oil temperature</i>)			
		Cage	To control the Motor 2 only if the Motor 1 is closed	INVERTER		

SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
132	RELAY 1	<i>Off</i>	Disabled	ALL	Off	
		<i>Start 3s</i>	To enable the Relay 1 for 3 seconds at every Start or reopening command			
		<i>Traffic light 1</i>	Traffic light management: the green light is switched-on only when the gate is open			
		<i>Traffic light in entrance</i>	By a Start command the traffic light in entrance turns green and the access priority is acquired while the traffic light in exit turns red. (with menu 89-TRAFFIC LIGHT BY RESERVATION in ON)			
		<i>Traffic light in exit</i>	By a Start command the traffic light in exit turns green and the access priority is acquired while the traffic light in entrance turns red. (with menu 89-TRAFFIC LIGHT BY RESERVATION in ON)			
		<i>Lock copy</i>	The Relay 1 will be ON for the time set on 78-LOCK menu			
		<i>Flashing light copy</i>	The Relay 1 repeats the flashing-light functions			
		<i>Courtesy light copy</i>	The Relay 1 will be ON for the time set on 88-COURTESY LIGHT menu			
		<i>Opening 1 limit switch</i>	The Relay 1 will be ON if the motor 1 opening limit switch is activated or if the motor 1 is in "Open" status			
		<i>Closing 1 limit switch</i>	The Relay 1 will be ON if the motor 1 closing limit switch is activated or if the motor 1 is in "Closed" status			
		<i>Opening 2 limit switch</i>	The Relay 1 will be ON if the motor 2 opening limit switch is activated or if motor 2 is in "Open" status			
		<i>Closing 2 limit switch</i>	The Relay 1 will be ON if the motor 2 closing limit switch is activated or if the motor 2 is in "Closed" status			
		<i>Tx Relay</i>	It is possible to activate the Relay 1 for 3 seconds by giving an impulse from the remote control			
		<i>Negative brake and Photocell 1 management</i>	The negative electric-brake is not active on the photocell intervention			
		<i>Negative brake 1 management</i>	Negative electric-brake (in ON with the gate in cycle and 1 second before the Start input)			
		<i>Positive brake 1 management</i>	Positive electric-brake (in ON with stationary gate)			
		<i>Opening electric-valve</i>	The Relay 1 is active during opening			
		<i>Closing electric-valve</i>	The Relay 1 is active during closing			
		<i>Clock 1 and 2</i>	The Relay will be active in the same time band set on menus 124 e 125			

SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
133	RELAY 2	<i>Off</i>	Disabled	ALL	<i>Off</i>	
		<i>Start 3s</i>	To enable the Relay 2 for 3 seconds at every Start or reopening command			
		<i>Traffic light 1</i>	Traffic light management: the green light is switched-on only when the gate is open			
		<i>Traffic light in entrance</i>	By a Start command the traffic light in entrance turns green and the access priority is acquired while the traffic light in exit turns red. (with menu 89-TRAFFIC LIGHT BY RESERVATION in ON)			
		<i>Traffic light in exit</i>	By a Start command the traffic light in exit turns green and the access priority is acquired while the traffic light in entrance turns red. (with menu 89-TRAFFIC LIGHT BY RESERVATION in ON)			
		<i>Lock copy</i>	The Relay 2 will be ON for the time set on 78-LOCK menu			
		<i>Flashing light copy</i>	The Relay 2 repeats the flashing-light functions			
		<i>Courtesy light copy</i>	The Relay 2 will be ON for the time set on 88-COURTESY LIGHT menu			
		<i>Opening 1 limit switch</i>	The Relay 2 will be ON if the motor 1 opening limit switch is activated or if the motor 1 is in "Open" status			
		<i>Closing 1 limit switch</i>	The Relay 2 will be ON if the motor 1 closing limit switch is activated or if the motor 1 is in "Closed" status			
		<i>Opening 2 limit switch</i>	The Relay 2 will be ON if the motor 2 opening limit switch is activated or if motor 2 is in "Open" status			
		<i>Closing 2 limit switch</i>	The Relay 2 will be ON if the motor 2 closing limit switch is activated or if the motor 2 is in "Closed" status			
		<i>Tx Relay</i>	It is possible to activate the Relay 2 for 3 seconds by giving an impulse from the remote control			
		<i>Negative brake and Photocell 2 management</i>	The negative electric-brake is not active on the photocell intervention			
		<i>Negative brake 2 management</i>	Negative electric-brake (in ON with the gate in cycle and 1 second before the Start input)			
		<i>Positive brake 2 management</i>	Positive electric-brake (in ON with stationary gate)			
		<i>Opening electric-valve</i>	The relay 2 is active during opening			
		<i>Closing electric-valve</i>	The relay 2 is active during closing			
		<i>Clock 3 and 4</i>	The relay will be active in the same time band set on menus 126 e 127			

SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
134	RELAY FV 1 (Relay on the FV MODULE 1)	Off	Disabled	INVERTER	It depends on motor	
		Positive brake management	Positive electric-brake (The relay FV1 will be ON only with stopped gate)			
		Negative brake management	Negative electric-brake (The relay FV1 will be ON only during operator cycle, 1 second before start and in case of photocell intervention)			
		Negative brake management and Photocell	Negative electric-brake (The relay FV1 will be ON only during operator cycle and 1 second before start, except in case of photocell intervention)			
		Fan	The relay on FV MODULE will activate for the whole cycle duration plus 2 further minutes			
		Tail Gate	The Relay FV 1 will enable only if the gate is closed			
		Copy Start	The Relay FV 1 will enable at every START command			
135	RELAY FV 2 (Relay on the FV MODULE 2)	Off	Disabled	INVERTER	It depends on motor	
		Positive brake management	Positive electric-brake (The relay FV2 will be ON only with stopped gate)			
		Negative brake management	Negative electric-brake (The relay FV2 will be ON only during operator cycle, 1 second before start and in case of photocell intervention)			
		Negative brake management and Photocell	Negative electric-brake (The relay FV2 will be ON only during operator cycle and 1 second before start, except in case of photocell intervention)			
		Fan	The relay on FV MODULE will activate for the whole cycle duration plus 2 further minutes			
		Tail Gate	The Relay FV 2 will enable only if the gate is closed			
		Copy Start	The Relay FV 2 will enable at every START command			
136	EFO	0% 100%	EFO function will be visible only with menu 3-MOTORS set on "5-Threephase/Bollards" This function generates an emergency closing with a higher speed than the set percentage and without considering the safety devices connected. <u>It works only with BOLLARDS</u> and through a command on the PEDESTRIAN START input	INVERTER	50%	
137	COMIS	0 350 mA	It shows the absorption of the accessories connected on input 20 (it only works if an accessory is connected at least)	ALL	----	
138	COMIS THRESHOLD	Off 350mA	Allows to set a maximum absorption threshold over which an error message appears (error message appears also when over 350 mA)	ALL	Off	

SPECIAL MENU		SET	DESCRIPTION	MODEL	DEFAULT	NOTE
140	THRESHOLD A OPENING 1	1 10 Ampere	Adjusts the amperometric intervention threshold of motor 1 in opening (over the set threshold motor will detect an obstacle)	INVERTER	It depends on motor	
141	THRESHOLD A CLOSING 1	1 10 Ampere	Adjusts the amperometric intervention threshold of motor 1 in closing (over the set threshold motor will detect an obstacle)	INVERTER	It depends on motor	
142	THRESHOLD A OPENING 2	1 10 Ampere	Adjusts the amperometric intervention threshold of motor 2 in opening (over the set threshold motor will detect an obstacle)	INVERTER	It depends on motor	
143	THRESHOLD A CLOSING 2	1 10 Ampere	Adjusts the amperometric intervention threshold of motor 2 in closing (over the set threshold the motor will detect an obstacle)	INVERTER	It depends on motor	
144	THRESHOLD A OPENING SLOWDOWN 1	1 10 Ampere	Adjusts the amperometric intervention threshold of motor 1 in slowdown during opening	INVERTER	It depends on motor	
145	THRESHOLD A CLOSING SLOWDOWN 1	1 10 Ampere	Adjusts the amperometric intervention threshold of motor 1 in slowdown during closing	INVERTER	It depends on motor	
146	THRESHOLD A OPENING SLOWDOWN 2	1 10 Ampere	Adjusts the amperometric intervention threshold of motor 2 in slowdown during opening	INVERTER	It depends on motor	
147	THRESHOLD A CLOSING SLOWDOWN 2	1 10 Ampere	Adjusts the amperometric intervention threshold of motor 2 in slowdown during closing	INVERTER	It depends on motor	
190	BASIC MENU	Press OK to exit the special menu. The special menu switches off automatically after 20 minutes				

Note 1: after initialization, the parameters set on menu **3 - MOTOR** and **104 - SELECT LIMIT SWITCH** always remain set to the value chosen during the programming operation

Note 2: if the menu **119 - DISPLAY WRITING SPEED** is set to the minimum value of 30%, the display writing speed will be low. On the contrary, if it is set to the maximum value of 100%, the writing speed will be very high

Please note: the writing speed will not change on the JOLLY 3 programmer

Dichiarazione di conformità
Declaration of Conformity

La SEA S.p.A. dichiara sotto la propria responsabilità e, se applicabile, del suo rappresentante autorizzato che il prodotto:

SEA S.p.A. declares under its proper responsibility and, if applicable, under the responsibility of its authorised representative that the product:

Descrizione / Description	Modello / Model	Marca / Trademark
UNIGATE 2-I (e tutti i suoi derivati / <i>and all its by-products</i>)	23023060	SEA
UNIGATE 1-I BIG (e tutti i suoi derivati / <i>and all its by-products</i>)	23023065	SEA
UNIGATE BR (e tutti i suoi derivati / <i>and all its by-products</i>)	23023092	SEA
UNIGATE 2PM (e tutti i suoi derivati / <i>and all its by-products</i>)	23023050	SEA

è costruito per essere incorporato in una macchina o per essere assemblato con altri macchinari per costruire una macchina ai sensi della Direttiva 2006/42/CE

is built to be integrated into a machine or to be assembled with other machinery to create a machine under the provisions of Directive 2006/42/CE

è conforme ai requisiti essenziali di sicurezza relativi al prodotto entro il campo di applicabilità delle Direttive Comunitarie 2014/35/UE e 2014/30/UE

is conforming to the essential safety requirements related to the product within the field of applicability of the Community Directives 2014/35/UE and 2014/30/UE

COSTRUTTORE o RAPPRESENTANTE AUTORIZZATO:
MANUFACTURER or AUTHORISED REPRESENTATIVE:

SEA S.p.A.

DIREZIONE E STABILIMENTO:

Zona industriale 64020 S.ATTO Teramo - (ITALY)

Tel. +39 0861 588341 r.a. Fax +39 0861 588344

[Http://www.seateam.com](http://www.seateam.com)

Luogo, data di emissione

Place, date of issue

Teramo, 06/10/2020

L'Amministratore

The Administrator

Ennio Di Saverio



TO THE ATTENTION OF BOTH INSTALLER AND END USER

MAINTENANCE: Periodically, based on the number of maneuvers performed over time and based on the type of operator, if a change in friction, malfunctioning or non-compliance with the previously set times are noticed, ***it would be advisable to reprogram the learning times on the control unit***

Periodically clean the optical systems of the photocells

REPLACEMENTS: Send request for spare parts to: **SEA S.p.A. - Teramo - ITALY** - www.seateam.com

SAFETY AND ENVIRONMENTAL COMPATIBILITY: Disposal of packaging materials and/or circuits should take place in an approved disposal facility





REGULAR PRODUCT DISPOSAL (electric and electronic waste)

(It's applicable in EU countries and in those ones provided with a differential waste collection)

This brand on the product or on documentation indicates that the product must not be disposed off together with other domestic waste at the end of its life cycle. In order to avoid any possible environmental or health damage caused by irregular waste disposal, we recommend to separate this product from other types of waste and to recycle it in a responsible way in order to provide the sustainable re-use of material resources. Domestic users are invited to contact the retailer where the product has been purchased or the local office to get all the information related to differential waste collection and recycling of this kind of product

IMMAGAZZINAMENTO

WAREHOUSING TEMPERATURES

T_{min}	T_{Max}	Dampness_{min}	Dampness_{Max}
- 20°C 	+ 65°C 	5% <i>not condensing</i>	90% <i>not condensing</i>

Materials handling must be made with appropriate vehicles

WARRANTY LIMITS - see the sales conditions

SEA S.p.A. reserves the right to make any required modification or change to the products and/or to this manual without any advanced notice obligation

GENERAL NOTICE FOR THE INSTALLER AND THE USER

1. **Read carefully these Instructions** before beginning to install the product. Store these instructions for future reference
2. Don't waste product packaging materials and /or circuits.
3. This product was designed and built strictly for the use indicated in this documentation. Any other use, not expressly indicated here, could compromise the good condition/operation of the product and/or be a source of danger. SEA S.p.A. declines all liability caused by improper use or different use in respect to the intended one.
4. The mechanical parts must be comply with Directives: Machine Regulation 2006/42/CE and following adjustments), Low Tension (2006/95/CE), electromagnetic Consistency (2004/108/CE) Installation must be done respecting Directives: EN12453 and En12445.
5. Do not install the equipment in an explosive atmosphere.
6. SEA S.p.A. is not responsible for failure to observe Good Techniques in the construction of the locking elements to motorize, or for any deformation that may occur during use.
7. Before attempting any job on the system, cut out electrical power and disconnect the batteries. Be sure that the earthing system is perfectly constructed, and connect it metal parts of the lock.
8. Use of the indicator-light is recommended for every system, as well as a warning sign well-fixed to the frame structure.
9. SEA S.p.A. declines all liability as concerns the automated system's security and efficiency, if components used, are not produced by SEA S.p.A..
10. For maintenance, strictly use original parts by SEA.
11. Do not modify in any way the components of the automated system.
12. The installer shall supply all information concerning system's manual functioning in case of emergency, and shall hand over to the user the warnings handbook supplied with the product.
13. Do not allow children or adults to stay near the product while it is operating. The application cannot be used by children, by people with reduced physical, mental or sensorial capacity, or by people without experience or necessary training. Keep remote controls or other pulse generators away from children, to prevent involuntary activation of the system.
14. Transit through the leaves is allowed only when the gate is fully open.
15. The User must not attempt to repair or to take direct action on the system and must solely contact qualified SEA personnel or SEA service centers. User can apply only the manual function of emergency.
16. The power cables maximum length between the central engine and motors should not be greater than 10 m. Use cables with 2,5 mm² section. Use double insulation cable (cable sheath) to the immediate vicinity of the terminals, in particular for the 230V cable. Keep an adequate distance (at least 2.5 mm in air), between the conductors in low voltage (230V) and the conductors in low voltage safety (SELV) or use an appropriate sheath that provides extra insulation having a thickness of 1 mm.

TERMS OF SALES

EFFICACY OF THE FOLLOWING TERMS OF SALE: the following general terms of sale shall be applied to all orders sent to SEA S.p.A. All sales made by SEA to all costumers are made under the prescription of this terms of sales which are integral part of sale contract and cancel and substitute all apposed clauses or specific negotiations present in order document received from the buyer.

GENERAL NOTICE The systems must be assembled exclusively with SEA components, unless specific agreements apply. Non-compliance with the applicable safety standards (European Standards EM12453 – EM 12445) and with good installation practice releases SEA from any responsibilities. SEA shall not be held responsible for any failure to execute a correct and safe installation under the above mentioned standards.

1) PROPOSED ORDER The proposed order shall be accepted only prior SEA approval of it. By signing the proposed order, the Buyer shall be bound to enter a purchase agreement, according to the specifications stated in the proposed order.

On the other hand, failure to notify the Buyer of said approval must not be construed as automatic acceptance on the part of SEA.

2) PERIOD OF THE OFFER The offer proposed by SEA or by its branch sales department shall be valid for 30 solar days, unless otherwise notified.

3) PRICING The prices in the proposed order are quoted from the Price List which is valid on the date the order was issued. The discounts granted by the branch sales department of SEA shall apply only prior to acceptance on the part of SEA. The prices are for merchandise delivered ex-works from the SEA establishment in Teramo, not including VAT and special packaging. SEA reserves the right to change at any time this price list, providing timely notice to the sales network. The special sales conditions with extra discount on quantity basis (Qx, Qx1, Qx2, Qx3 formula) is reserved to official distributors under SEA management written agreement.

4) PAYMENTS The accepted forms of payment are each time notified or approved by SEA. The interest rate on delay in payment shall be 1.5% every month but anyway shall not be higher than the max. interest rate legally permitted.

5) DELIVERY Delivery shall take place, approximately and not peremptorily, within 30 working days from the date of receipt of the order, unless otherwise notified. Transport of the goods sold shall be at Buyer's cost and risk. SEA shall not bear the costs of delivery giving the goods to the carrier, as chosen either by SEA or by the Buyer. Any loss and/or damage of the goods during transport, are at Buyer's cost.

6) COMPLAINTS Any complaints and/or claims shall be sent to SEA within 8 solar days from receipt of the goods, proved by adequate supporting documents as to their truthfulness.

7) SUPPLY The concerning order will be accepted by SEA without any engagement and subordinately to the possibility to get it's supplies of raw material which is necessary for the production; Eventual completely or partially unsuccessful executions cannot be reason for complains or reservations for damage. SEA supply is strictly limited to the goods of its manufacturing, not including assembly, installation and testing. SEA, therefore, disclaims any responsibility for damage deriving, also to third parties, from non-compliance of safety standards and good practice during installation and use of the purchased products.

8) WARRANTY The standard warranty period is 12 months. This warranty time can be extended by means of expedition of the warranty coupon as follows:

SILVER: The mechanical components of the operators belonging to this line are guaranteed for 24 months from the date of manufacturing written on the operator.

GOLD: The mechanical components of the operators belonging to this line are guaranteed for 36 months from the date of manufacturing written on the operator.

PLATINUM: The mechanical components of the operators belonging to this line are guaranteed for 36 months from the date of manufacturing written on the operator. The base warranty (36 months) will be extended for further 24 months (up to a total of 60 months) when it is acquired the certificate of warranty which will be filled in and sent to SEA S.p.A. The electronic devices and the systems of command are guaranteed for 24 months from the date of manufacturing. In case of defective product, SEA undertakes to replace free of charge or to repair the goods provided that they are returned to SEA repair centre. The definition of warranty status is by unquestionable assessment of SEA. The replaced parts shall remain propriety of SEA. Binding upon the parties, the material held in warranty by the Buyer, must be sent back to SEA repair centre with fees prepaid, and shall be dispatched by SEA with carriage forward. The warranty shall not cover any required labour activities.

The recognized defects, whatever their nature, shall not produce any responsibility and/or damage claim on the part of the Buyer against SEA. The guarantee is in no case recognized if changes are made to the goods, or in the case of improper use, or in the case of tampering or improper assembly, or if the label affixed by the manufacturer has been removed including the SEA registered trademark No. 804888. Furthermore, the warranty shall not apply if SEA products are partly or completely coupled with non-original mechanical and/or electronic components, and in particular, without a specific relevant authorization, and if the Buyer is not making regular payments. The warranty shall not cover damage caused by transport, expendable material, faults due to non-conformity with performance specifications of the products shown in the price list. No indemnification is granted during repairing and/or replacing of the goods in warranty. SEA disclaims any responsibility for damage to objects and persons deriving from non-compliance with safety standards, installation instructions or use of sold goods. The repair of products under warranty and out of warranty is subject to compliance with the procedures notified by SEA.

9) RESERVED DOMAIN A clause of reserved domain applies to the sold goods; SEA shall decide autonomously whether to make use of it or not, whereby the Buyer purchases propriety of the goods only after full payment of the latter.

10) COMPETENT COURT OF LAW In case of disputes arising from the application of the agreement, the competent court of law is the tribunal of Teramo. SEA reserves the faculty to make technical changes to improve its own products, which are not in this price list at any moment and without notice. SEA declines any responsibility due to possible mistakes contained inside the present price list caused by printing and/or copying. The present price list cancels and substitutes the previous ones. The Buyer, according to the law No. 196/2003 (privacy code) consents to put his personal data, deriving from the present contract, in SEA archives and electronic files, and he also gives his consent to their treatment for commercial and administrative purposes.

Industrial ownership rights: once the Buyer has recognized that SEA has the exclusive legal ownership of the registered SEA brand num.804888 affixed on product labels and / or on manuals and / or on any other documentation, he will commit himself to use it in a way which does not reduce the value of these rights, he won't also remove, replace or modify brands or any other particularity from the products. Any kind of replication or use of SEA brand is forbidden as well as of any particularity on the products, unless preventive and expressed authorization by SEA.

In accomplishment with art. 1341 of the Italian Civil Law it will be approved expressly clauses under numbers:

4) PAYMENTS - 8) GUARANTEE - 10) COMPETENT COURT OF LAW



SEA S.p.A.

Zona industriale 64020 S.ATTO Teramo - (ITALY)

Tel. +39 0861 588341 r.a. Fax +39 0861 588344

www.seateam.com

seacom@seateam.com